Panasonic

Hybrid IP-PBX

User Manual

Model KX-TDA30/KX-TDA100/KX-TDA200

With Compliments
Absolute Phone & Data

Thank you for purchasing a Panasonic Hybrid IP-PBX.
Please read this manual carefully before using this product and save this manual for future use.

KX-TDA30: MPR Version 2.2
KX-TDA100/KX-TDA200: MPR Version 2.0

Feature Highlights

Call Centre

This PBX can establish Incoming Call Distribution Groups (ICD Group) by which a large volume of calls from the external customers could be received. One extension can act as the supervisor, and monitor other group members.



1.8 Utilising the Call Centre (Page 126)

Voice Mail Integration

You can forward your calls to a voice processing system and let calling parties leave messages in your mailbox when you are unable to receive calls.

1.9.5 If a Voice Processing System is Connected (Page 138)

Wireless System

This PBX optionally supports a Portable Station (PS) system. PSs can be used on the PBX with other wired telephones.



Appendix (Page 203)

PC Phone/PC Console

This PBX supports the PC Phone/PC Console when your computer is connected to certain Panasonic telephones via USB interface. The PC Phone/PC Console provides advanced control and monitoring of your PBX.



Consult your dealer

Easy Operation

If you are using a certain Panasonic telephone that is equipped with a Navigator Key/Jog Dial and a display, it helps you to access the desired feature easily. Also, you will be informed of the arrival of an incoming call or a message waiting by the lamp if it is equipped.



1.1 Before Operating the Telephones (Page 14)

Call Record (Station Message Detail Recording)

This PBX can record or print out call information: date, time, extension no., dialled no., duration, etc.



Consult your dealer

With Compliments
Absolute Phone & Data

Built-in Simplified Voice Message

You can set incoming calls to be redirected to your message box to let callers leave voice messages when you are unable to answer the phone.



1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only) (Page 91)

With Compliments
Absolute Phone & Data

In This Manual,

- Proprietary Telephone is abbreviated as "PT".
  Single Line Telephone is abbreviated as "SLT".
  Portable Station is abbreviated as "PS".
  Proprietary Telephone with a Display is abbreviated as "Display PT".
  Digital Proprietary Telephone is abbreviated as "DPT".
- The suffix of each model number is omitted.
- The illustrations of the PBX are based on the KX-TDA200.
- The following icons are used frequently.

Hints Conditions

Notice

Product specifications are subject to change without notice.

With Compliments
Absolute Phone & Data

Important Information

WARNING

- **THIS UNIT MAY ONLY BE INSTALLED AND SERVICED BY QUALIFIED SERVICE PERSONNEL.**
- **IF DAMAGE TO THE UNIT EXPOSES ANY INTERNAL PARTS, DISCONNECT THE POWER SUPPLY CORD IMMEDIATELY AND RETURN THE UNIT TO YOUR DEALER.**
- **UNPLUG THIS UNIT FROM THE AC OUTLET IF IT EMITS SMOKE, AN ABNORMAL SMELL OR MAKES UNUSUAL NOISE. THESE CONDITIONS CAN CAUSE FIRE OR ELECTRIC SHOCK. CONFIRM THAT SMOKE HAS STOPPED AND CONTACT AN AUTHORISED PANASONIC FACTORY SERVICE CENTRE.**
- **WHEN RELOCATING THE EQUIPMENT, FIRST DISCONNECT THE TELECOM CONNECTION BEFORE DISCONNECTING THE POWER CONNECTION. WHEN THE UNIT IS INSTALLED IN THE NEW LOCATION, RECONNECT THE POWER FIRST, AND THEN RECONNECT THE TELECOM CONNECTION.**
- **THIS UNIT IS EQUIPPED WITH AN EARTHED PLUG. FOR SAFETY REASONS THIS PLUG MUST ONLY BE CONNECTED TO AN EARTHED OUTLET THAT HAS BEEN INSTALLED ACCORDING TO APPLICABLE REGULATIONS.**
- **TO PREVENT POSSIBLE FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**
- **THE POWER SUPPLY CORD IS USED AS THE MAIN DISCONNECT DEVICE. ENSURE THAT THE AC OUTLET IS LOCATED NEAR THE EQUIPMENT AND IS EASILY ACCESSIBLE.**
- **TO PROTECT THIS UNIT FROM STATIC ELECTRICITY, DO NOT TOUCH ANY EXTERNAL CONNECTORS OF THE UNIT.**

With Compliments
Absolute Phone & Data

Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
2. Avoid using wired telephones during an electrical storm. There is a remote risk of electric shock from lightning.
3. Do not use a telephone in the vicinity of a gas leak to report the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire, as they may explode. Dispose according to local regulations.

SAVE THESE INSTRUCTIONS

CE

The KX-TDA30E, KX-TDA30NE, KX-TDA30GR, and KX-TDA30CE are designed to interwork with the:

- Analogue Public Switched Telephone Network (PSTN) of European countries
- Pan-European Integrated Services Digital Network (ISDN) using ISDN basic rate access

The KX-TDA100E/KX-TDA200E, KX-TDA100NE/KX-TDA200NE, KX-TDA100GR/KX-TDA200GR, and KX-TDA100CE/KX-TDA200CE are designed to interwork with the:

- Analogue Public Switched Telephone Network (PSTN) of European countries
- Pan-European Integrated Services Digital Network (ISDN) using ISDN basic rate access
- Pan-European Integrated Services Digital Network (ISDN) using ISDN primary rate access
- ONP 2048 kbit/s digital structured leased lines (D2048S)

Panasonic Communications Co., Ltd./Panasonic Communications Company (U.K.) Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC.
Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting:

http://doc.panasonic.de

Contact:
Panasonic Services Europe GmbH
Panasonic Testing Centre
Winsbergring 15, 22525 Hamburg, F.R. Germany

With Compliments
Absolute Phone & Data

Attention

- Keep the unit away from heating appliances and devices that generate electrical noise such as fluorescent lamps, motors, and televisions. These noise sources can interfere with the performance of the PBX.
- This unit should be kept free of dust, moisture, high temperature (more than 40 °C), and vibration, and should not be exposed to direct sunlight.
- If you are having problems making calls to outside destinations, follow this procedure to test the outside lines:

  1. Disconnect the PBX from all outside lines.

  2. Connect known working single line telephones (SLTs) to those outside lines.

  3. Make a call to an external destination using those SLTs.

  If a call cannot be carried out correctly, there may be a problem with the outside line that the SLT is connected to. Contact your telephone company.
  If all SLTs operate properly, there may be a problem with your PBX. Do not reconnect the PBX to the outside lines until it has been serviced by an authorised Panasonic Factory Service Centre.
- Never attempt to insert wires, pins, etc. into the vents or holes of this unit.
- Wipe the unit with a soft cloth. Do not clean the unit with abrasive powders or with chemical agents such as benzene or thinner.
- When using a Panasonic proprietary telephone (PT), use only the correct Panasonic handset.
- For users of PC Phone (Free Licence Version) shipped with KX-T7601 USB Module:
  All features of the PC Phone software are available for 90 days from the date of installation.
  After this period expires, the following buttons on the Operation Screen will become unavailable:
  - Recording
  - TAM
  - Voice Memo
  - Text Memo
  - Speed

  To continue using any of the corresponding features after the trial period, please purchase KX-TDA0350 (PC Phone, 5 licences).

With Compliments
Absolute Phone & Data

For Future Reference

Please print, record, and retain the following information for future reference.

Note

The serial number of this product can be found on the label affixed to the unit. You should record the model number and the serial number of this unit as a permanent record of your purchase to aid in identification in the event of theft.

MODEL NO.	_____
SERIAL NO.	_____
DATE OF PURCHASE	_____
NAME OF DEALER	_____
DEALER'S ADDRESS	_____
	_____
	_____
	_____
DEALER'S TEL. NO.	_____

With Compliments
Absolute Phone & Data

Table of Contents

1 Operation 13
1.1 Before Operating the Telephones 14
1.1.1 Before Operating the Telephones 14
1.2 Making Calls 25
1.2.1 Basic Calling 25
1.2.2 Easy Dialling 30
1.2.3 Redial 34
1.2.4 When the Dialled Line is Busy or There is No Answer 35
1.2.5 Accessing the ISDN Service (ISDN Service Access) 44
1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice) 45
1.2.7 Calling without Restrictions 46
1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA]) 47
1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting) 50
1.3 Receiving Calls 51
1.3.1 Answering Calls 51
1.3.2 Answering Hands-free (Hands-free Answerback) 52
1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) 53
1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) 54
1.3.5 Using the ANSWER/RELEASE Button 55
1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) 57
1.4 During a Conversation 58
1.4.1 Transferring a Call (Call Transfer) 58
1.4.2 Holding a Call 62
1.4.3 Talking to Two Parties Alternately (Call Splitting) 66
1.4.4 Answering Call Waiting 68
1.4.5 Multiple Party Conversation 72
1.4.6 Mute 81
1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor) 82
1.4.8 Using the Headset (Headset Operation) 83
1.5 Before Leaving Your Desk 85
1.5.1 Forwarding Calls 85
1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only) 91
1.5.3 Showing a Message on the Caller's Telephone Display (Absent Message) 101
1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock) 103
1.6 Making/Answering an Announcement 105
1.6.1 Paging 105
1.6.2 Answering/Denying a Paging Announcement 107
1.6.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting) 108
1.7 Setting the Telephone According to Your Needs 111
1.7.1 Setting the Alarm (Timed Reminder) 111
1.7.2 Refusing Incoming Calls (Do Not Disturb [DND]) 113
1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) 115
1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]) 116
1.7.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) 117

With Compliments Absolute Phone & Data

1.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) 118
1.7.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny) 119
1.7.8 Turning on the Background Music (BGM) 120
1.7.9 Protecting Your Line against Notification Tones (Data Line Security) 121
1.7.10 Checking the Time Service Status 122
1.7.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone) 123
1.7.12 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) 124
1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear) 125
1.8 Utilising the Call Centre 126
1.8.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) 126
1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) 129
1.8.3 Forwarding a Waiting Call (Manual Queue Redirection) 132
1.9 Using User-supplied Equipment 133
1.9.1 If a Doorphone/Door Opener is Connected 133
1.9.2 If an External Relay is Connected 135
1.9.3 If an External Sensor is Connected 136
1.9.4 If a Host PBX is Connected 137
1.9.5 If a Voice Processing System is Connected 138
1.10 After Moving to a New Location in the Office 144
1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension) 144
1.11 Using a Display Proprietary Telephone 145
1.11.1 Using the Call Log 145
1.11.2 Using the Directories 149
1.11.3 Accessing System Features (System Feature Access) 156

2 Manager Operation 157
2.1 Control Features 158
2.1.1 Extension Control 158
2.1.2 Time Service Mode Control 159
2.1.3 Restriction Level Control (Dial Tone Transfer) 161
2.1.4 Turning on the External Background Music (BGM) 162
2.1.5 Recording Outgoing Messages (OGM) 163
2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out) 166
2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features) 167
2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor 173

3 Customising Your Phone & System 175
3.1 Customising Your Phone (Personal Programming) 176
3.1.1 Customising Your Phone (Personal Programming) 176
3.1.2 Settings on the Programming Mode 178
3.1.3 Customising the Buttons 188
3.2 Manager Programming 193
3.2.1 Programming Information 193
3.2.2 Manager Programming 194
3.3 Customising Your System (System Programming) 196
3.3.1 Programming Information 196
3.3.2 System Programming 199

4 Appendix 203

With Compliments
Absolute Phone & Data

4.1 Troubleshooting 204
4.1.1 Troubleshooting 204
4.2 Feature Number Table 207
4.2.1 Feature Number Table 207
4.3 What is This Tone? 218
4.3.1 What is This Tone? 218
4.4 Revision History 222
4.4.1 KX-TDA100/KX-TDA200 MPR Version 1.1 222
4.4.2 KX-TDA100/KX-TDA200 MPR Version 2.0 223
4.4.3 KX-TDA30 MPR Version 1.1 224
4.4.4 KX-TDA30 MPR Version 2.0 225
4.4.5 KX-TDA30 MPR Version 2.2 226

Index 227

With Compliments
Absolute Phone & Data

With Compliments
Absolute Phone & Data

Section 1
Operation

This chapter shows you step by step how to use each feature. Read this chapter to become familiar with the many useful features of this PBX.

With Compliments
Absolute Phone & Data

1.1 Before Operating the Telephones

1.1.1 Before Operating the Telephones

What Kind of Telephone Can Be Used?

You can use a single line telephone (SLT), such as a rotary pulse telephone or a Panasonic proprietary telephone (PT) such as the KX-T7636 or KX-NT136. You can also use a Panasonic Portable Station (PS) such as the KX-TCA255 or KX-TD7690. Use the feature depending on the telephone you are using. If you are using a Panasonic proprietary telephone with a special feature button such as REDIAL or a display (Display PT) or both, you can follow the operation with the button or display messages for easy programming.
If you use a large display telephone (e.g., KX-T7636), you can follow the displayed messages to use the features. If your telephone does not have feature buttons and/or a display, you may operate the PBX by entering a feature number instead. Follow the operation for your type of telephone.
If you use a Console, you can use the buttons on the Console as the buttons on the connected proprietary telephone.

- If you use a Panasonic proprietary telephone which does not have feature buttons, you may change one of the unused flexible buttons to a feature button. Refer to "3.1.3 Customising the Buttons".

With Compliments
Absolute Phones & Data

Registration for Your Portable Station (PS)

You must register your PS in the PBX and determine its extension number before initial use. For PS registration, consult your dealer.

Feature Numbers

To use certain features, you need to enter specified feature numbers (and an additional parameter, if required).
There are two types of feature numbers as follows:

- Flexible feature number
- Fixed feature number

Fixed feature numbers cannot be changed. However, you can change the flexible numbers to other numbers for easier use. If you want to change the numbers, consult your dealer. In this manual, the default numbers (factory installed) are used for operations.

A flexible number is shown as 0 (half-shaded key). Use the new programmed number if you have changed the feature number. Write the new number in "4.2.1 Feature Number Table" (Appendix).

Notice

The default value of a flexible feature number may vary depending on country/area. For more details, consult your dealer.

If you use a single line telephone which does not have the "✳" or "#" keys;
it is not possible to access features that have "✳" or "#" in their feature numbers.

Tone

You will hear various tones, during or after an operation, for confirmation. Refer to "4.3.1 What is This Tone?" (Appendix).

Display

In this manual, you will see "the display ...". This refers to the display of a Panasonic proprietary telephone. If your telephone is not a Panasonic display proprietary telephone, the message will not be displayed.
If you use a Panasonic display proprietary telephone, the display helps you confirm the settings. Some proprietary telephones also give you easy access to features. A message is displayed depending on the feature. By pressing the corresponding button on the side or at the bottom of the display, or pressing the Navigator Key, you can access the desired feature.
Furthermore, depending on the display proprietary telephone, you can operate features or make calls using the display message. Refer to "1.11 Using a Display Proprietary Telephone".

Notice

In this manual, the display messages are described in English.

Your Extension Number

If you use a Panasonic display proprietary telephone, you can check your own extension number on the display. Press the TRANSFER button or Soft (S1) button while on-hook.

Using a Navigator Key/Jog Dial/Volume Key

The Navigator Key can be used for the display contrast and the volume control or you can search for desired items on the display. Press the Navigator Key/Volume Key or rotate the Jog Dial in the desired direction. The contrast or the volume level and the items will change as follows:

Navigator Key	Jog Dial	Volume Key
Up (Level **increases**) **Left** ENTER **Right** **Down** (Level **decreases**)	**Left** (anti-clockwise) Level **decreases** **Right** (clockwise) Level **increases**	**Up** (Level **increases**) **Down** (Level **decreases**)

With Compliments
Absolute Phone & Data

Examples

The displays and the illustrations shown as examples are from a telephone connected to the KX-TDA200.

Restrictions

Some features may be restricted at your extension under system programming. Consult your manager or dealer.

Icon Descriptions

The following icons show you the feature availability, notes and action to use the features.

	This feature cannot be used with a single line telephone.		Seize an outside line (One of the following). • Press the CO button. • Dial automatic line access number 0 or 9. • Dial outside line group access number and outside line group number.
	See "Programming" for Related Programming if necessary.		
	Off-hook (One of the following). • Lift the handset. • Press the SP-PHONE button. • Press the MONITOR button. (To start talking, lift the handset.) • Press TALK button.		Press the Call button on the Doorphone.
	On-hook (One of the following). • Hang up. • Press the SP-PHONE button. • Press the MONITOR button. • Press CANCEL button.		Press the hookswitch lightly.
	Press the corresponding feature button on the proprietary telephone.		Talk.
desired no.	Enter the required number. <Example> account code Enter the account code.		You will hear a busy, confirmation, dial, ring or ringback tone. B. Tone: Busy Tone C. Tone: Confirmation Tone D. Tone: Dial Tone R. Tone: Ring Tone R. B. Tone: Ringback Tone
extension no.	Dial an extension number.	outside phone no.	Dial outside phone number.
phone no.	Dial the telephone number.		

With Compliments Absolute Phone & Data

When You Use a Panasonic Proprietary Telephone

If you use a Panasonic proprietary telephone and the Console, they may have some of the useful feature buttons described below. For a PS user, refer to "Operating Instructions" for PS. These buttons make operations simple. The illustrations may differ from the buttons on your telephone.

Fixed Buttons

	**CO**: Used to make or receive an outside call. (Button assignment is required.) Also used as feature buttons. (Button assignment is required.) (Only the outside line "number" [e.g., 1, 2] may be shown on some telephones.)		**SP-PHONE**: Used for hands-free operation.
	**AUTO DIAL/STORE**: Used for System/Personal Speed Dialling or storing programme changes.		**PAUSE**: Used to insert a pause when storing a telephone number. This button also functions as the PROGRAM button when there is no PROGRAM button on your telephone.
	**REDIAL**: Used to redial the last dialled number.		**MESSAGE**: Used to leave a message waiting indication or call back the party who left the message waiting indication.

With Compliments
Absolute Phone & Data

	**INTERCOM**: Used to make or receive intercom calls.		**Soft Buttons**: Used to select the item displayed on the bottom of the display.
	**MONITOR**: Used for hands-free dialling. You can monitor the party's voice in hands-free mode.		**AUTO ANS (Auto Answer)/MUTE**: Used to receive an incoming call in hands-free mode or mute the microphone during a conversation.
	**TRANSFER**: Used to transfer a call to another party.		**HOLD**: Used to place a call on hold.

With Compliments
Absolute Phone & Data

	**FLASH/RECALL**: Used to disconnect the current call and make another call without hanging up. This button also functions as a CANCEL button while on-hook.		**CONF (Conference)**: Used to establish a multiple party conversation.
	**VOICE CALL/MUTE**: Used to monitor an intercom call automatically, but it cannot be used for hands-free conversations. It also mutes the handset microphone during a conversation.		**Call Forwarding (FWD)/Do Not Disturb (DND)**: Used to perform Call Forwarding (FWD) or Do Not Disturb (DND).
	PROGRAM: Used to enter and exit the Programming mode.		**ANSWER**: Used to answer an incoming call.

With Compliments
Absolute Phone & Data

	**RELEASE**: Used to disconnect the line.		**Navigator Key/Jog Dial/Volume Key**: Used to adjust the volume and the display contrast or select desired items.
	Programmable Feature (PF): *Located on the upper part of the CO button array or on the DSS Console.* Assigns the desired button and used to access the stored feature. Mostly used as a One-touch Dialling button. (Only the "F and number" may be shown on some telephones.)		**MODE**: Used to shift the display to access various features.
	SELECT: Used to select the displayed item or to call the displayed phone number.		**SHIFT**: Used to access the second level of Soft button features.
	ENTER: Used to confirm the selected item.		**CANCEL**: Used to cancel the selected item.

With Compliments Absolute Phone & Data

Customised Buttons

If the term is in parentheses like (Account) in this section, it means a flexible button has been made into an "Account" button. To customise, refer to "3.1.3 Customising the Buttons".

Buttons	Feature
Loop-CO (L-CO)	Used to access an idle outside line for making outside calls. Incoming outside calls from any outside line arrive at this button.
Group-CO (G-CO)	Used to access an idle outside line in a specified outside line group for making outside calls. Incoming calls from outside lines in the assigned outside line group arrive at this button.

Buttons	Feature
Single-CO (S-CO)	Used to access a specified outside line for making or receiving outside calls.
Direct Station Selection (DSS)	Used to access an extension with one touch. It is also possible to be changed to the other feature button.
One-touch Dialling	Used to access a desired party or system feature with one touch.
Incoming Call Distribution Group (ICD Group)	Used to access a specified incoming call distribution group for making or receiving calls.
Message	Used to leave a message waiting indication or call back the party who left the message waiting indication.
Message for Another Extension	Used to have a Message button for another extension.
Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls	Used to forward all calls to a specified destination or refuse.
FWD/DND—Outside calls	Used to forward outside calls to a specified destination or refuse.
FWD/DND—Intercom calls	Used to forward intercom calls to a specified destination or refuse.
Group FWD—Both calls	Used to forward all the calls to your group to a specified destination.
Group FWD—Outside calls	Used to forward the outside calls to your group to a specified destination.
Group FWD—Intercom calls	Used to forward the intercom calls to your group to a specified destination.
Account	Used to enter an account code.
Conference	Used to establish a multiple party conversation.
Terminate	Used to disconnect the current call and make another call without hanging up.
External Feature Access (EFA)	Used to access special features offered by a host PBX or a telephone company.
Charge Reference	Used to check the total call charge for your own extension.
Call Park	Used to park or retrieve a call in a preset parking zone.
Call Park (Automatic Park Zone)	Used to park a call in an idle parking zone automatically.
Call Log	Used to show the incoming call information.
Call Log for ICD Group	Used to have a Call Log button for incoming call distribution group.
Log-in/Log-out	Used to switch between the log-in and log-out mode.
Log-in/Log-out of a specified group	Used to have a Log-in/Log-out button for another incoming call distribution group.
Log-in/Log-out for all groups	Used to have a Log-in/Log-out button for all groups.
Hurry-up	Used to transfer the longest waiting call in the queue of an incoming call distribution group to the overflow destination.
Wrap-up	Used to switch the wrap-up status, Ready and Not Ready mode.
System Alarm	Used to confirm a PBX error. For more details, consult your dealer.
Time Service (Day/Night/ Lunch/Break)	Used to switch the time service mode.

With Compliments
Absolute Phone & Data

Buttons	Feature
Answer	Used to answer an incoming call.
Release	Used to disconnect the line during or after a conversation or to complete a Call Transfer.
Toll Restriction/Call Barring	Used to change the toll restriction/call barring level of other extension users temporarily.
ISDN Service	Used to access an ISDN service.
Calling Line Identification Restriction (CLIR)	Used to switch between the CLIP and CLIR services.
Connected Line Identification Restriction (COLR)	Used to switch between the COLP and COLR services.
ISDN-Hold	Used to transfer a call using telephone company.
Headset	Used to talk using the headset.
Time Service Switching Mode (Automatic/Manual)	Used to switch the time service mode, Automatic or Manual.
Two-way Record	Used to record a conversation into your own mailbox.
Two-way Transfer	Used to record a conversation into the mailbox of a specific extension.
One-touch Two-way Transfer	Used to record a conversation into the mailbox of a specific extension with one touch.
Live Call Screening (LCS)	Used to monitor your own voice mailbox while an incoming caller is leaving a message and, if desired, intercept the call.
Voice Mail Transfer	Used to transfer a call to the mailbox of a specified extension.
Network Direct Station Selection (NDSS)	Used to access an extension connected to other PBXs in the network with one touch.
CTI	Used to access CTI features. For more details, consult your dealer.
Check-in	Used to switch the room status of extensions from Check-out to Check-in.
Check-out	Used to switch the room status of extensions from Check-in to Check-out.

With Compliments
Absolute Phone & Data

How to Follow the Steps

An example of system operation is shown below.

Calling Another Extension

Feature title

To call an extension (Intercom Call)

PT/SLT/PS



Off-hook. Dial **extension number** or press **DSS**. Talk.

Operation steps
The description of the icons are explained on "Icon Descriptions".

Conditions

- The DSS button light shows the current status as follows:
  Off: The extension is idle.
  Red on: Your or another extension is using the line.

Hints

- To call using a directory, refer to "1.11.2 Using the Directories".
- **For quick operation**
  If you are an operator or dial some extensions frequently, DSS buttons are useful.
- **Hands-free Operation**
  You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
  Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
  Create or edit a Direct Station Selection (DSS) button.

Programming References: The related or required programming is noted.

With Compliments
Absolute Phone & Data

Connection Example

This diagram shows you a connection example.



With Compliments Absolute Phone & Data

1.2 Making Calls

1.2.1 Basic Calling

- Calling Another Extension
- Calling an Outside Party
- Making a Call to a Private Network (TIE Line Access)
- Using an Account Code (Account Code Entry)

Calling Another Extension

To call an extension (Intercom Call)

When your telephone does not access an outside line automatically



When your telephone accesses an outside line automatically





- The DSS button light shows the current status as follows:
  Off: The extension is idle.
  Red on: Your or another extension is using the line.

With Compliments Absolute Phone & Data

- To call using a directory, refer to "1.11.2 Using the Directories".
- **For quick operation**
  If you are an operator or dial some extensions frequently, DSS buttons are useful.
- **Hands-free Operation**
  You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
  Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
  Create or edit a Direct Station Selection (DSS) button.

To call an operator (Operator Call)

You can call an extension or a group assigned as the operator.

PT/SLT/PS



- The operator call number (default) varies depending on country/area.
  For more details, consult your dealer.

Calling an Outside Party

You have to seize an outside line before dialling an outside phone number because external calls are made via your PBX.
Select one of the following methods:

To select an idle outside line automatically (Automatic Line Access)

PT/SLT/PS



- The automatic line access number (default) varies depending on country/area.
  For more details, consult your dealer.

With Compliments
Absolute Phone & Data

To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)

PT/SLT/PS



Off-hook. Press **G-CO** or enter **outside line group access number** and then **outside line group number** (2 digits). Dial **outside phone number**. Talk.

To select the specified outside line

PT/PS

Off-hook. Press **S-CO**. Dial **outside phone number**. Talk.

With Compliments Absolute Phone & Data

- Each of the S-CO button or G-CO button light shows the current status as follows:
  Off: The line is idle.
  Red on: The line is in use.
- You may be restricted from making a call to the specified outside party. To make a call, refer to "1.2.7 Calling without Restrictions".

- **To confirm number before dialling**, you can enter a phone number and confirm it on the display and then go off-hook. (Predialling)
- **Call Charge Reference**
  You can confirm your total call charges by pressing the Charge Reference button.
- **To make a call to another party without going on-hook**, press the FLASH/RECALL button. It will re-access the outside line and provide external dial tone. Pressing the Terminate button will provide intercom dial tone. You can dial the new phone number without going on/off-hook.
- **Hands-free Operation**
  You can make an outside call and have a conversation in hands-free mode using the SP-PHONE button.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
  Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
  Create or edit a Loop-CO (L-CO) button, a Group-CO (G-CO) button, a Single-CO (S-CO) button, a Terminate button or a Charge Reference button.

Making a Call to a Private Network (TIE Line Access)

You can access extensions connected to other PBXs in a private network.

To call

PT/SLT/PS

Off-hook. Enter **7**. Dial **private phone number**. Talk.

To call with one touch

PT/PS



Off-hook. Press **NDSS**. Talk.

- **To start monitoring another PBX extension after customising an NDSS button,** go off-hook, press the NDSS button, and go on-hook.
  The NDSS button light will show the current status as follows:
  Off: The extension is idle.
  Red on: The extension is busy.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Network Direct Station Selection (NDSS) button.

With Compliments
Absolute Phone & Data

Using an Account Code (Account Code Entry)

You may give a specified account code to extension users and check their telephone usage. You can specify an account code for each client and check the call duration.

PT/SLT/PS



- **A Panasonic proprietary telephone extension user** can enter an account code during a conversation and when hearing reorder tone after the other party hangs up.
- Account codes may use the digits "0" through "9".
- **If you enter the wrong code,** press the "✳" key and re-enter the account code.

- You may not be able to make an outside call without an account code. Entry mode is assigned to each user. Ask your manager for your mode.
- **For your convenience,** you can store the code with the phone number in the memory (e.g., Speed Dialling).

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an Account button.

With Compliments Absolute Phone & Data

1.2.2 Easy Dialling

This is convenient for frequently dialled phone numbers.

– With a One-touch Button (One-touch Dialling)
– Using Numbers Stored at Your Extension (Personal Speed Dialling)
– Using Numbers Stored in the PBX (System Speed Dialling)
– To a Preset Number by Going Off-hook (Hot Line)
– Using a Preprogrammed Number (Quick Dialling)

With a One-touch Button (One-touch Dialling)

You can store a phone number into the flexible button for one-touch operation.

PT/PS

Off-hook.

Press **One-touch Dialling**.

With Compliments Absolute Phone & Data

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a One-touch Dialling button, store the desired phone number or feature number.

Using Numbers Stored at Your Extension (Personal Speed Dialling)

You can store numbers at your extension for your personal use.
This feature is also known as Station Speed Dialling.

To store a phone number

PT/SLT

Off-hook. Enter ✳30. Enter **personal speed dialling number** (2 digits). Enter **desired phone number** (max. 32 digits). Enter #. On-hook.

Enter outside line access number before outside phone number.

- The number of personal speed dialling numbers available per extension (default: 10 numbers stored in locations "00" to "09") can be increased to a maximum of 100. For more details, consult your dealer.

To dial

PT/SLT



- To call using a directory, refer to "1.11.2 Using the Directories".

Using Numbers Stored in the PBX (System Speed Dialling)

You can make calls using speed dialling numbers stored in the PBX.

PT/SLT/PS



- To call using a directory, refer to "1.11.2 Using the Directories".

With Compliments Absolute Phone & Data

To a Preset Number by Going Off-hook (Hot Line)

You can make an outside call simply by going off-hook if you have preprogrammed your phone. This feature is also known as Pickup Dialling.

To store a phone number



To set/cancel



To dial

With Compliments
Absolute Phone & Data

- **To call another party**, dial the desired party's phone number before the preprogrammed number is dialled.
- You should assign the intercom line as the seized line when going off-hook. (Preferred Line Assignment—Outgoing)
- If cancelling Hot Line is difficult because this feature is activated immediately after going off-hook, consult your dealer.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**
  Select the seized line when going off-hook.

Using a Preprogrammed Number (Quick Dialling)

You can make a call simply by pressing the preprogrammed number for quick dialling. For details, consult your manager or dealer.

PT/SLT/PS

Off-hook.

quick dialling no.

Dial **quick dialling number** (max. 4 digits).

- It is a useful feature for Hotel.
  For example, to dial the Room Service, dial the digit "3", not the full extension number.

With Compliments
Absolute Phone & Data

1.2.3 Redial

This is convenient when calling the same outside party again.

– Redialling the Last Number You Dialled (Last Number Redial)

Redialling the Last Number You Dialled (Last Number Redial)

PT/SLT/PS



Off-hook. Press **REDIAL** or enter **#**.

- Up to 32 digits can be stored and redialled.
- After pressing REDIAL, if you hear a busy tone again, press REDIAL to retry.

- **Automatic Redial**

  To redial automatically, press the SP-PHONE button and then the REDIAL button, or press the REDIAL button directly. It will keep trying the busy number until the called party answers or until a specified timeout.
  You can perform other tasks during dialling. To cancel, press the FLASH/RECALL button.
  Some outside lines may not support this feature.

  This feature is not available for the KX-T7665 and PS.

With Compliments
Absolute Phone & Data

1.2.4 When the Dialled Line is Busy or There is No Answer

- Reserving a Busy Line (Automatic Callback Busy)
- Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])
- Sending a Call Waiting Notification (Call Waiting)
- Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)
- Joining an Existing Call (Executive Busy Override)
- Monitoring Another Extension (Call Monitor)
- To an Extension Refusing the Call (DND Override)

Reserving a Busy Line (Automatic Callback Busy)

You can set the telephone to receive callback ringing:

- when a dialled extension becomes idle.
- when your desired outside line that is in use by another extension becomes idle.

You cannot set Automatic Callback Busy for a busy party outside of the PBX.

When you answer the callback ringing:

- For an outside call: The line is seized.
- For an intercom call: The called extension starts ringing automatically.

To set (for both extension and outside line)

PT/SLT/PS

While hearing a busy tone

Enter **6**. On-hook.

To answer the callback ringing from an idle extension

PT/SLT/PS

While hearing a callback ringing

Off-hook. Talk.

With Compliments
Absolute Phone & Data

To answer the callback ringing from an idle outside line

PT/SLT/PS

While hearing a callback ringing



Off-hook. Dial **outside phone number**. Talk.

- If you do not answer the callback ringing within 10 seconds, this feature will be cancelled.

To cancel callback ringing (Automatic Callback Busy Cancel)

PT/SLT/PS

Off-hook. Enter ✱**46**. On-hook.

Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])

You can set the telephone to receive callback ringing when a busy called party on an ISDN line becomes free.
When you answer the callback ringing, the called party's telephone number is automatically dialled.

PT/SLT/PS

While hearing a busy tone

Enter **6**. On-hook.

With Compliments
Absolute Phone & Data

To answer while hearing a callback ringing

PT/SLT/PS

Off-hook.

To cancel (CCBS Cancel)

PT/SLT/PS



Off-hook. Enter ✱46. On-hook.

- If you do not answer within a specified time period, this feature will be cancelled.
- Availability of this feature depends on the ISDN service of your telephone company.

Sending a Call Waiting Notification (Call Waiting)

You can inform the called party that your call is waiting.
This feature is also known as Busy Station Signalling (BSS).

PT/SLT/PS

While hearing a busy tone

Enter **1**.

- **Depending on the other party's telephone**, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can send a call announcement through the handset (Whisper OHCA), if they are having another conversation using the handset.
  Refer to "1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/ Whisper OHCA)". For telephones capable of using the OHCA and Whisper OHCA features, consult your dealer.

With Compliments Absolute Phone & Data

Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)

◆ ***For a caller***
When the called extension is busy or does not answer your call, you can leave a notification so that the called party may call you back.
◆ ***For a called extension***
As a message receiver, the Message button light or Message/Ringer Lamp lets you know that a call has been received. If you receive notification, you can call the caller back by a simple operation.



◆ For a caller

To leave a message waiting indication

PT/SLT/PS

When the called extension is busy or does not answer



Press **MESSAGE** or enter **4**.

On-hook.

To leave/cancel a message waiting indication

PT/SLT/PS



Off-hook.

Enter ✱70.

Enter **1** to leave or **0** to cancel.

Enter **desired extension number**.

On-hook.

With Compliments
Absolute Phone & Data

◆ For a called extension

To check the left message and call back

PT/PS

While on-hook

Press **MESSAGE** until the desired extension appears. → Off-hook. → Talk.

To call back

PT/SLT/PS



Off-hook. → Press **MESSAGE** or enter ✳**70** and then **2**. → Talk.

To clear message waiting indications left on your extension

PT/SLT/PS

Off-hook. → Enter ✳**70**. → Enter **0**. → Dial **your extension number**. → On-hook.

With Compliments
Absolute Phone & Data

- The Message button light or Message/Ringer Lamp shows the current status as follows:
  Off: No message
  Red on: You have a message.
- The display shows the messages starting with the most recent call.
- At a called extension, the MESSAGE button allows you to clear message waiting indications if you do not want to call the callers back. To clear, press the MESSAGE button and then press the soft button.
- On your PT, you can establish one or more Message for Another Extension buttons. These buttons can accept the message waiting notification of other extensions or various incoming call distribution groups.
  In other words, you can monitor the message waiting notifications of other telephones.
- A single line telephone extension user will receive a special dial tone as message waiting notification when going off-hook.
- **KX-TDA100/KX-TDA200 only**
  The message waiting lamp of a single line telephone can also let you know that you have a message in the same way as the Message button.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Message button or Message for Another Extension button.

With Compliments
Absolute Phone & Data

Joining an Existing Call (Executive Busy Override)

The preprogrammed extension can call someone who is busy on the telephone and establish a three-party conversation.

To join an intercom call

PT/SLT/PS

● ***Party joining the call***



A three-party conversation is now established.

● ***Parties in the conversation***

During a conversation

To join an outside call

PT/PS

● ***Party joining the call***

A three-party conversation is now established.

● ***Parties in the conversation***

During a conversation

With Compliments Absolute Phone & Data

To leave a three-party conversation with an outside party and let the two other parties talk (originating extension only)


PT/PS
● Originating party in the conversation
During the three-party conversation
TRANSFER
Press TRANSFER.
On-hook.
You leave the three-party conversation.
● Party who joined the call
During the three-party conversation
The other extension and the outside party stay on the line.
Talk to the outside party.

- To join another conversation, you must have Executive Busy Override enabled at your extension. For more details, consult your dealer.
- For the originating extension to leave a three-party conversation, that party's extension must be enabled through COS programming to transfer calls to outside lines.
- The third party can leave the conversation by simply going on-hook.

◆ For the originating extension

To talk to each party alternately



- You can also deny others the possibility of joining your conversation (Default: Allow). Refer to "1.7 Setting the Telephone According to Your Needs".

With Compliments Absolute Phone & Data

Monitoring Another Extension (Call Monitor)

The preprogrammed extension can monitor another extension.

To monitor

PT/SLT/PS



To an Extension Refusing the Call (DND Override)

The preprogrammed extension can call someone who has set the DND feature.

PT/SLT/PS



With Compliments
Absolute Phone & Data

1.2.5 Accessing the ISDN Service (ISDN Service Access)

You can access services provided by the ISDN.

To access

PT/PS



- Availability of features depends on the ISDN service of your telephone company.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an ISDN Service button.

With Compliments
Absolute Phone & Data

1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)

The caller can alternate the alerting method, either ring or voice, when making an intercom call.
On the other hand, any extension can set the alerting method, either ring or voice, when receiving an intercom call.

Ringing (Default): You can call the other party with a ring tone.

Voice-calling: You can talk to the other party immediately after confirmation tone.



To change the method

PT/SLT/PS

After dialling

Enter ✱.

Talk.

- If the called party uses a single line telephone or portable station, Voice-calling is not available.
- This feature is not available when the called party's telephone is in the Voice Call Deny mode.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Alternate Receiving—Ring/Voice**
  Select the alerting method, either ring or the other party's voice.

With Compliments
Absolute Phone & Data

1.2.7 Calling without Restrictions

– Using Your Calling Privileges at Another Extension (Remote COS Access)

Using Your Calling Privileges at Another Extension (Remote COS Access)

You can use your calling privileges (Class of Service) at another extension. You may override restrictions which have been set. To use this feature, an original extension number and an extension PIN (Personal Identification Number) are required. You can make a call by entering a verified code and verified code PIN. For the available verified code, ask your manager.

To call (Walking COS)


PT/SLT/PS
PIN: Personal Identification Number
✳ 4 7
your extension no.
extension PIN
C.Tone & D.Tone
desired phone no.
Off-hook.
Enter ✳47.
Dial your extension number.
Enter extension PIN (max. 10 digits).
Dial desired phone number.
If a wrong extension PIN is entered, you hear an alarm tone.
Seize outside line before entering outside phone number.

To call with a verified code (Verified Code Entry)



With Compliments Absolute Phone & Data

1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])

– Calling through DISA

Calling through DISA

When outside callers access extensions in the PBX, a prerecorded message greets the caller and gives information about how to access an extension. You do not need the operator's assistance.
You may be able to access system features or call an outside party with your password depending on the security mode. Ask your manager for the mode assigned to your PBX.



With Compliments
Absolute Phone & Data

To call an extension

From Outside Telephone

PIN: Personal Identification Number

● ***In No Security Mode/Trunk Security Mode***

Off-hook. → Dial **DISA phone number.** → R.B.Tone & DISA message → Dial **desired extension number.**

● ***In All Security Mode***

Off-hook. → Dial **DISA phone number.** → R.B.Tone & DISA message → Enter ✱**47**. → Dial **your extension number.** Or enter ✱ and then **verified code.** →→ Enter **extension PIN** or **verified code PIN** (max.10 digits). → C.Tone & D.Tone → Dial **desired extension number.**

To call an outside party

From Outside Telephone

PIN: Personal Identification Number

●*In No Security Mode*

Off-hook.

Dial **DISA phone number**.

Dial **outside phone number**.

Seize outside line before dialling outside phone number.

●*In Trunk Security Mode/All Security Mode*



Off-hook.

Dial **DISA phone number**.

Enter ✳**47**.

Dial **your extension number**.
Or enter ✳ and then **verified code**.



Enter **extension PIN** or **verified code PIN** (max.10 digits).

Dial **outside phone number**.

Seize outside line before dialling outside phone number.

To retry

From Outside Telephone

To dial a different number during a conversation with an outside party or while hearing the ringback, reorder, or busy tone

Enter ✳.

Dial **phone number**.

Dial a line access number as the first digit when calling an outside party.

With Compliments
Absolute Phone & Data

- **WARNING**
  There is a risk that fraudulent telephone calls will be made using the Outside-to-Outside Call feature of DISA.
  The cost of such calls will be billed to the owner/renter of the PBX.
  To protect the PBX from this kind of fraudulent use, we strongly recommend:
  a) Enabling DISA security (Trunk Security or All Security).
  b) Keeping your passwords (verified code PIN/extension PIN) secret.
  c) Selecting complex, random PINs that cannot be easily guessed.
  d) Changing PINs regularly.
- **Time limit**
  Both parties will hear an alarm tone fifteen seconds before the specified time limit. To extend, press any dial button except ✳.
- **If Built-in Automated Attendant service is set**, you can access the desired extension simply by pressing a single digit (0-9) from the options given the prerecorded message.

With Compliments
Absolute Phone & Data

1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)

You can set the following features on your telephone from another extension or through DISA.

- Call Forwarding (FWD)/Do Not Disturb (DND)
- Changing the Log-in/Log-out Status of Extensions
- Absent Message
- Extension Dial Lock
- Time Service—Changing the Time Mode (Day/Night/Lunch/Break)

From another extension



Through DISA



With Compliments Absolute Phone & Data

1.3 Receiving Calls

1.3.1 Answering Calls

PT/SLT/PS

Off-hook.

Talk.

Select one of the following methods:
· Lift the handset to receive the preferred line.
(Default: Ringing line is selected.)
· Press the SP-PHONE button.
· Press the flashing CO, INTERCOM or ICD Group button directly.
· Press the ANSWER button.

- The ICD Group button light shows the current status as follows:
  Off: Idle
  Green on: The line is in use. (You are using the line.)
  Red on: Your extension is in Log-out mode from the incoming call distribution group.

- **Hands-free Operation**
  You can receive a call and have a conversation in hands-free mode using the SP-PHONE button.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—
  Preferred Line Assignment—Incoming
  Select the seized line when going off-hook.
  Alternate Receiving—Ring/Voice
  Select the alerting method, either ring or the other party's voice.
- 3.1.3 Customising the Buttons
  Create or edit an Incoming Call Distribution Group (ICD Group) button.

With Compliments
Absolute Phone & Data

1.3.2 Answering Hands-free (Hands-free Answerback)

You can answer an incoming call without going off-hook as soon as the line is connected. When an intercom call arrives, you will hear the caller talking without the phone ringing. When an outside call arrives, you will hear the caller talking after a preprogrammed number of rings. Hands-free Answerback for outside calls requires system programming. Consult your dealer.

To set/cancel

PT

While on-hook

Press
AUTO ANS.

- The AUTO ANS button light shows the current status as follows:
  Off: Not set
  On: Set
- For a PS user, refer to "Operating Instructions" for PS.

With Compliments
Absolute Phone & Data

1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)

- Answering a Call from Another Telephone (Call Pickup)
- Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)

Answering a Call from Another Telephone (Call Pickup)

You can answer an incoming call that is ringing at another extension or group from your phone without leaving your desk.
The following types of pickup are available:

Group Call Pickup: Picks up a call within your group.
Directed Call Pickup: Picks up a specified extension's call.



- **If you receive a call waiting tone,** you can ask a third party to pick up your second call with Directed Call Pickup.
- If there are multiple incoming calls for the same group, the longest waiting call is received first.

Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)

You can deny or allow other people to pick up your calls.



With Compliments
Absolute Phone & Data

1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

You can be notified of incoming outside calls through an external speaker. These calls can be answered from any extension.

Through an external speaker

<For users of KX-TDA100/KX-TDA200>

PT/SLT/PS

While hearing a tone

Off-hook. ▶ Enter ✳ **42**. ▶ Dial **speaker number** (1 digit). C.Tone Talk.

<For users of KX-TDA30>

PT/SLT/PS

While hearing a tone

Off-hook. ▶ Enter ✳ **42**. ▶ Enter **1**. C.Tone Talk.

With Compliments
Absolute Phone & Data

- You can also receive a paging announcement via a speaker with this operation.

1.3.5 Using the ANSWER/RELEASE Button

The ANSWER and RELEASE buttons are convenient for operators using headsets.
With the ANSWER button, you can answer all incoming calls.
With the RELEASE button, you can disconnect the line during or after a conversation, or complete transferring a call.

To answer

PT

Press **ANSWER**. Talk.

To transfer a call

PT

During a conversation

Press **TRANSFER**. Press **DSS** or dial **desired phone number**. Press **RELEASE.**

Seize outside line before dialling outside phone number.

With Compliments Absolute Phone & Data

To talk to a waiting caller

PT

While hearing a call waiting tone

Press **ANSWER**. Talk.

To transfer an outside call to an extension with a one-touch operation

PT

During a conversation



Press **DSS**.

Press **RELEASE**.

The other party is placed on hold and the destination extension is called immediately.

To end a conversation

PT

During a conversation

Press **RELEASE**.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an Answer button or a Release button.

With Compliments
Absolute Phone & Data

1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])

You can ask your telephone company to trace a malicious calling party during a conversation or after the calling party hangs up.
You will receive the information on the malicious call later on.

To request MCID

PT/SLT/PS

During a conversation or when hearing a reorder tone after the calling party hangs up.



Press **TRANSFER** or **Recall/hookswitch**.

Enter ✱7✱3.

Talk or on-hook.

- Availability of this feature depends on the ISDN service of your telephone company.

With Compliments
Absolute Phone & Data

1.4 During a Conversation

1.4.1 Transferring a Call (Call Transfer)

– Transferring to an Extension on the PBX
– Transferring to an Outside Party Using the PBX Service
– Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)

- You can transfer a held call without talking by going on-hook.
  If a call is not retrieved within a specified time, you will hear an alarm as a reminder. And, if an outside call is not answered within a specified time, it is automatically disconnected.
- **If you hear an alarm tone,** the destination extension did not answer the call. Answer the call.

Transferring to an Extension on the PBX

To transfer

PT/PS

During a conversation



Press **TRANSFER**.

Press **DSS** or dial **extension number**.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

SLT

During a conversation

Press **Recall/ hookswitch**.

Dial **extension number**.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

With Compliments Absolute Phone & Data

To transfer with one touch (One-touch Transfer)

PT/PS

During a conversation

Press **DSS**. Talk. On-hook.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

- Even if the transferred party does not answer, you can go on-hook.

Transferring to an Outside Party Using the PBX Service

Some extensions may be restricted from performing this feature.

PT/PS

During a conversation

Press **TRANSFER**. Seize **outside line**. Dial **outside phone number**. Talk. On-hook.

The call is transferred.

SLT

During a conversation



Press **Recall/hookswitch**. Seize **outside line**. Dial **outside phone number**. Talk. On-hook.

The call is transferred.

With Compliments
Absolute Phone & Data

- **Time limit**
  Both the caller and the transferred party will hear an alarm tone fifteen seconds before a specified time period.
- **To return to the held call before the destination answers,** press the TRANSFER button, corresponding CO, ICD Group or INTERCOM button, or the hookswitch.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Direct Station Selection (DSS) button.

Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)

PT/PS

During a conversation

Press **ISDN-Hold**. Dial **phone number**. Talk. On-hook.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

PT/PS

During a conversation

Press **TRANSFER**. Enter ✱**62**. Dial **phone number**. Talk. On-hook.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

SLT

During a conversation

Press **Recall/ hookswitch**. Enter ✱**62**. Dial **phone number**. Talk. On-hook.

You do not have to inform the destination extension about where the call has been transferred from. This can be disregarded.

With Compliments Absolute Phone & Data

- To retrieve the held call, press the TRANSFER button, Recall/hookswitch.
- Even if you go on-hook while transferring a call, it is transferred.
- After the call is transferred, the line becomes idle.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an ISDN-Hold button.

With Compliments
Absolute Phone & Data

1.4.2 Holding a Call

– Holding
– Holding in a System Parking Zone (Call Park)

- **If a call is not retrieved within a specified time**, you will hear an alarm as a reminder. And, if an outside call is not answered within a specified time, it is automatically disconnected.

Holding

There are two types of hold. The difference between them is that other people can retrieve your held call (Regular Hold) or not (Exclusive Call Hold). As they can be alternated, ask your manager what the current mode is.

To hold (Call Hold)

PT/PS

During a conversation



Press **HOLD,** or press **TRANSFER** and then enter ✱**50**.

On-hook.

SLT

During a conversation

Press **Recall/ hookswitch**.

Enter ✱**50**.

On-hook.

With Compliments Absolute Phone & Data

To retrieve a call (Call Hold Retrieve)

PT/SLT/PS

● ***At the holding extension (Call Hold Retrieve)***



Off-hook. Press flashing **CO** or **INTERCOM,** or enter ✳**50**. Talk.

● ***To retrieve an outside call from another extension—only Regular Hold (Call Hold Retrieve–Specified with a held line number)***



Off-hook. Press **CO,** or enter ✳**53** and then **held line number** (3 digits). Talk.

● ***To retrieve an intercom call or outside call from another extension—only Regular Hold (Call Hold Retrieve–Specified with a holding extension number)***

Off-hook. Enter ✳**51**. Press **DSS** or dial **holding extension number**. Talk.

With Compliments
Absolute Phone & Data

- The CO or INTERCOM button light shows the current status as follows:
  - Regular Hold mode
    Flashing green slowly: Your held call
    Flashing red: Another extension's held call
  - Exclusive Call Hold mode
    Flashing green rapidly: Your held call
    Red on: Another extension's held call
- **Hold Mode Change (PT only)**
  After pressing the HOLD button, if you press the HOLD button again, the status switches from the Regular Hold mode to the Exclusive Call Hold mode or from the Exclusive Call Hold mode to the Regular Hold mode.

- **For simple operation,** you can automatically hold a call by pressing another CO, ICD Group or INTERCOM button, only if preprogrammed **(Automatic Call Hold)**. Consult your dealer.

Holding in a System Parking Zone (Call Park)

You can put a call on hold in a common parking zone of the PBX so that any extension can retrieve the parked call. You can use this feature as a transferring feature.
A call can be put into either a specified parking zone (Specified) or any idle parking zone (Auto). If a Call Park button and Call Park (Automatic Park Zone) button have been established, you can select either way to park by simply pressing the corresponding button.
When a call is parked automatically, or more than one call has been parked at the same time, you need to specify the parking zone number to retrieve the required call.

To set

PT/PS

During a conversation

Press **Call Park**.

PT/PS

During a conversation

On-hook.

Press **TRANSFER**. Enter ✱**52**. Enter a specified **parking zone number** (2 digits) or press ✱ to park at an idle parking zone automatically.

If you hear a busy tone, enter another parking zone number or press ✱ again.

SLT

During a conversation

Press **Recall/ hookswitch**. Enter ✱**52**. Enter a specified **parking zone number** (2 digits). On-hook.

If you hear a busy tone, enter another parking zone number.

With Compliments
Absolute Phone & Data

To retrieve (Call Park Retrieve)

PT/PS

Press a flashing **Call Park**.

PT/SLT/PS

Off-hook. Enter ✳**52**. Dial **stored parking zone number** (2 digits). Talk.

- If a call is parked automatically, confirm the parking zone number on the display.

- **If you hear a reorder tone when retrieving a parked call,** there is no held call. Confirm the stored parking zone number.
- After you park a call, you can perform other operations.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Call Park button or Call Park (Automatic Park Zone) button.

With Compliments
Absolute Phone & Data

1.4.3 Talking to Two Parties Alternately (Call Splitting)

When talking to one party while the other party is on hold, you can swap the calls back and forth (alternately).

To alternate between the parties leaving one party on hold temporarily

PT/PS

During a conversation

Press **TRANSFER**. | Press **DSS** or dial **the other party's extension number**. | Talk to the other party. | Press **TRANSFER**. | Talk to the original party.

The other party will be on hold.

SLT

During a conversation

Press **Recall/ hookswitch**. | Dial **the other party's extension number**. | Talk to the other party. | Press **Recall/ hookswitch**. | Talk to the original party.

The other party will be on hold.

With Compliments Absolute Phone & Data

To leave the conversation and then let the two parties talk

PT/PS

During a conversation

Press **TRANSFER**. | Press **DSS** or dial **the other party's extension number**. | Talk to the other party. | Press **TRANSFER**. | On-hook.

SLT

During a conversation

Press **Recall/ hookswitch**. | Dial **the other party's extension number**. | Talk to the other party. | Press **Recall/ hookswitch**. | On-hook.

With Compliments
Absolute Phone & Data

1.4.4 Answering Call Waiting

- Answering Call Waiting in the PBX
- Answering Call Waiting from the Telephone Company

Answering Call Waiting in the PBX

During a conversation, a call waiting tone or voice announcement through the speaker or the handset occurs when an outside call has been received or another extension is letting you know a call is waiting. You must activate this feature to use it. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])
You can answer the second call by disconnecting (1) or holding (2) the current call.

1. To disconnect the current call and then talk to the new party

PT/SLT/PS

While hearing a tone

On-hook. Off-hook. Talk to the new party.

2. To hold the current call and then talk to the new party

PT/PS

While hearing a tone



Press **HOLD**. Press **CO** or **INTERCOM**. Talk to the new party.

Disregard this step if both parties are extensions.

SLT

While hearing a tone



Press **Recall/hookswitch**. Enter ✱ **50.** Talk to the new party.

With Compliments Absolute Phone & Data

After talking to the new party (second call), you can disconnect (2.1) or hold (2.2) it and then retrieve the first call.

2.1 To disconnect the second call and then talk to the original party

PT/PS

During a conversation



On-hook. Off-hook. Press **CO** or **INTERCOM**. Talk to the original party.

PT/SLT/PS

During a conversation



On-hook. Off-hook. Enter ✱ **50**. Talk to the original party.

2.2 To hold the second call and then talk to the original party

After holding it, you can talk to the original party. Then, you can disconnect it and then talk to the new party again.

PT/PS

During a conversation



Press **HOLD**. Press **CO** or **INTERCOM**. Talk to the original party.

On-hook. Off-hook. Press **CO** or **INTERCOM**. Talk to the new party.

With Compliments Absolute Phone & Data

SLT

During a conversation



- **Depending on your telephone,** you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can receive an announcement through the handset (Whisper OHCA), if you are having a conversation using the handset.
  Refer to "1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/ Whisper OHCA)". For telephones capable of using the OHCA and Whisper OHCA features, consult your dealer.
- The caller's name or number is displayed for five seconds in fifteen second intervals while waiting to be answered.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Call Waiting Tone Type Selection**
  If you select "Tone 1", you will hear the same tone for Call Waiting from an outside party and an extension. If you select "Tone 2", you will hear different tones for Call Waiting from an outside party and an extension.



With Compliments Absolute Phone & Data

Answering Call Waiting from the Telephone Company

This is an optional telephone company service. You can receive a call waiting tone and the caller's information. For details, consult your telephone company.



- **To return to the original party,** repeat the operation.
- In this case, the FLASH/RECALL button on proprietary telephones must be in External Feature Access (EFA) mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an External Feature Access (EFA) button.

With Compliments
Absolute Phone & Data

1.4.5 Multiple Party Conversation

- Adding Other Parties during a Conversation (Conference)
- Leaving a Conference (Unattended Conference)
- Leaving a Conference (Leaving Three-party Conference)
- Letting a Third Party Join Your Call (Privacy Release)
- Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)

Adding Other Parties during a Conversation (Conference)

You can add one or more parties to your conversation.

To establish a conference call

PT/PS

During a conversation

Press **CONF** or **TRANSFER**. Dial **desired phone number**. Talk to the new party. Press **CONF**. Talk with multiple parties.

Seize outside line before dialling outside phone number.

PT/PS

During a conversation

Press **TRANSFER**. Dial **desired phone number**. Talk to the new party. Press **TRANSFER**. Enter **3**.

Seize outside line before dialling outside phone number.

Talk with multiple parties.

With Compliments Absolute Phone & Data

SLT

During a conversation

Press **Recall/ hookswitch**. Dial **desired phone number**. Talk to the new party. Press **Recall/ hookswitch**. Enter **3**.

Seize outside line before dialling outside phone number.

Talk with multiple parties.

To establish a conference call when receiving a call from an outside party during a two-party conversation

PT/PS

While hearing a call waiting tone

Press **HOLD**. Press the flashing **CO**. Talk to the new party. Press **CONF** or **TRANSFER**.



Press the flashing **CO** or **INTERCOM** corresponding to the original party. Talk to the original party. Press **CONF,** or press **TRANSFER** and then enter **3**. Talk with multiple parties.

With Compliments Absolute Phone & Data

To add four or more parties to a conference

PT/PS

During a conversation



To add an outside party on hold to a conference

PT/PS

During a 3- to 7-party conference

To talk to two parties alternately in a three-party conversation

PT/PS

During a conversation

Press **TRANSFER**.

SLT

During a conversation



Press **Recall/hookswitch**.

With Compliments
Absolute Phone & Data

To disconnect one party and then talk to the other in a three-party conversation

PT/PS

During a conversation

Press **TRANSFER** once or twice to establish a conversation with the party to be disconnected.

Press **FLASH/RECALL**.*

Press the flashing **CO** or **INTERCOM** corresponding to the party on hold.

Talk.

The other party will be put on hold.

- * In this case, the FLASH/RECALL button on a proprietary telephone must be in Flash/Recall mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.
- During a three-party conversation, pressing the TRANSFER button or Recall/hookswitch alternates between the other parties in the conversation.
- You can have a conference with a maximum of eight parties (comprising intercom or outside lines) simultaneously.
- During a conversation involving four or more parties, you cannot disconnect one party and maintain the conversation with the other parties.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Conference button.

Leaving a Conference (Unattended Conference)

The person who originated a conference can leave the conference, and allow the other parties to continue the conversation.

To leave a conference

PT/PS

During 3- to 7-party conference

Press **CONF**.

On-hook.

With Compliments
Absolute Phone & Data

To return while others are talking

PT



Press flashing green **CO** or **INTERCOM**.

To complete a conversation

PT/SLT/PS

During a conversation

On-hook.

- **Time limit**
  Both parties will hear an alarm tone before a specified timeout. The originating extension user will hear an alarm tone before timeout. The call is disconnected when the timer runs out unless the originating extension returns to the conference.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Conference button.

Leaving a Conference (Leaving Three-party Conference)

The person who originated a conference with two other parties can leave the conference, and allow the other parties to continue the conversation.

To leave a conference

PT/PS

During a three-party conference

Press **TRANSFER**.

On-hook.

With Compliments
Absolute Phone & Data

SLT

During a three-party conference

Press **Recall/hookswitch**.

On-hook.

To complete a conversation

PT/SLT/PS

During a conversation

On-hook.

- To leave a conference call involving an outside party or parties and have the conference continue, it is necessary to enable your extension to transfer calls to outside lines through COS programming. Consult your dealer.

With Compliments
Absolute Phone & Data

Letting a Third Party Join Your Call (Privacy Release)

You can let a third party join your current outside call and establish a three-party conversation. You can also leave the conversation and then let the two other parties talk.

To let a third party join your conversation and establish a three-party conversation



To leave the conversation and let the two other parties talk



With Compliments
Absolute Phone & Data

- Only an S-CO button can be used for this operation.
- To leave a three-party conversation and have the conversation continue, it is necessary to enable your extension to transfer calls to outside lines through COS programming. For more details, consult your dealer.

Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)

PT/PS

During a conversation



Press **ISDN-Hold**. | Dial **desired phone number**. | Talk to the new party. | Press **CONF**. | Talk with multiple parties.

Seize outside line before dialling outside phone number.

PT/PS

During a conversation



Press **TRANSFER**. | Enter ✳ **62**. | Dial **desired phone number**. | Talk to the new party. | Press **TRANSFER**.

Seize outside line before dialling outside phone number.

Enter **3**. | Talk with multiple parties.

With Compliments Absolute Phone & Data

SLT

During a conversation



Press **Recall/ hookswitch**. | Enter ✳**62**. | Dial **desired phone number**. | Talk to the new party. | Press **Recall/ hookswitch**.

Seize outside line before dialling outside phone number.

Enter **3**. | Talk with multiple parties.

To complete a conversation

PT/SLT/PS

During a conversation

On-hook.

With Compliments Absolute Phone & Data

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an ISDN-Hold button.

1.4.6 Mute

You can disable the microphone or the handset to consult privately with others in the room while listening to the other party on the phone through the speaker or the handset.

To set/cancel

PT

During a conversation

Press **MUTE**.

- The AUTO ANS/MUTE or VOICE CALL/MUTE button light shows the current status as follows:
  Off: Normal
  Flashing red: Mute
- If mute is used during OHCA, it will become Handset Mute.

With Compliments
Absolute Phone & Data

1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor)

You can let other people in the room listen to the conversation through the speaker while continuing the conversation using the handset.

To set/cancel

PT

During a conversation using the handset

Press **SP-PHONE**.

- The SP-PHONE button light shows the current status as follows:
  Off: The voice is heard through the handset.
  On: The voice is heard through the speaker and the handset.
- This feature requires system programming. Ask your manager.
- This feature may not be available with certain proprietary telephones. For more details, consult your dealer.

- **Hands-free operation**
  You can have a conversation in hands-free mode using the SP-PHONE button. You can perform other tasks simultaneously.
- **Helpful hints for hands-free operation:**
  - **If it is difficult to hear the other party's voice:**
    Increase the volume using the Navigator Key, Jog Dial, or Volume Key.
  - **If the other party has difficulty hearing you:**
    Decrease the volume.
  - **If the other party reports that your voice echoes:**
    Use the telephone in a room that has curtains, carpeting or both.
  - **If parts of the conversation cannot be heard:**
    If you and the other party speak at the same time, parts of your conversation may be lost. To avoid this, try to speak alternately.

With Compliments Absolute Phone & Data

1.4.8 Using the Headset (Headset Operation)

You can have a conversation using a headset.
In this case, you must select "Headset on" in programming mode or set the Headset button on (red) in advance.
This feature is also known as Handset/Headset Selection.

To talk using the headset

PT

Press **SP-PHONE**.

To use the handset during a conversation using the headset

PT

Off-hook.

To talk in hands-free mode during a conversation using the headset

PT

Press red **Headset**.

- The Headset button light shows the current status as follows:
  Off: Headset mode off
  Red on: Headset mode on
- This feature is not available for the KX-T7665.

With Compliments
Absolute Phone & Data

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Headset Operation**
  Select the equipment to use.
- 3.1.3 Customising the Buttons
  Create or edit a Headset button.

With Compliments
Absolute Phone & Data

1.5 Before Leaving Your Desk

1.5.1 Forwarding Calls

– Forwarding Your Calls (Call Forwarding [FWD])
– Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)

Forwarding Your Calls (Call Forwarding [FWD])

You can have your incoming calls forwarded to a specified destination.

All Calls:
All calls are forwarded. Preset extensions may also forward from their own receiving group.
Busy:
All calls are forwarded when your extension is busy.
No Answer:
All calls are forwarded when you do not answer the call within a specified time period.
Busy/No Answer (BSY/NA):
All calls are forwarded when you do not answer within a specified time period or when your extension is busy.
Follow Me (From):
If you fail to set the above-mentioned "All Calls" to forward before you leave your desk, you can set the same feature from the destination extension.



With Compliments
Absolute Phone & Data

- You can set the floating extension number of a voice mail group or the SVM card as a forward destination.
- You can set your mobile telephone as the forward destination. The voice mail can be used to receive calls if you are unable to answer.
- Incoming calls can be forwarded up to four times.
- **Boss & Secretary feature**
  The extension which has been set as the destination can call the forwarding extension.

  <Example>



To set/cancel



To set from another extension



With Compliments
Absolute Phone & Data

- When using a proprietary telephone, you can set or cancel Call Forwarding by pressing the FWD/DND button (fixed button) instead of "✳710".

To set the timer for "No Answer" and "Busy/No Answer"

PT/SLT/PS



Off-hook. Enter ✳713. Enter **time** (**seconds** [2 digits]). On-hook.

To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)

PT/SLT/PS *ICD Group: Incoming Call Distribution Group*



Off-hook. Enter ✳71. Enter **4** to **6** as you desire. Enter **1** to set or **0** to cancel. Enter **ICD Group extension number**.

Enter **destination extension number**. Or enter **outside line access number** and then **outside phone number**. Enter **#**. On-hook.

With Compliments of Absolute Phone & Data

- The FWD/DND button light shows the current status as follows:
  Off: Both features are not set.
  Red on: FWD mode
  Flashing red slowly: DND mode
- The Group FWD button light shows the current status as follows:
  Off: No set
  Red on: FWD mode

- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

  (1) When in the FWD/DND Cycle Switch Mode:
  Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:

  (2) When in the FWD/DND Setting Mode:
  Pressing the FWD/DND button (fixed button) while in idle status will take you directly to the programming mode for the FWD/DND setting.
  (Refer to "3.1.2 Settings on the Programming Mode".)

  Note

  A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- Transferred outside calls are also forwarded to the destination assigned for outside calls.
- When intercom calls are set to be handled differently from outside calls (forwarding type, forward destination), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, and/or Group FWD—Outside calls and Group FWD—Intercom calls, because:

  a) the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) and the Group FWD—Both calls button will indicate the setting for either outside calls or intercom calls, but not both.

  Note

  The FWD icon on PS display reflects the setting for outside calls only.

  b) pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) or the Group FWD—Both calls button will not change the FWD or DND mode for intercom calls and outside calls separately.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons, or Group FWD (Both calls, Outside calls, Intercom calls) buttons.

With Compliments
Absolute Phone & Data

Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)

All calls are forwarded to an outside party using ISDN. The following types of call forwarding are provided by the ISDN service.

– Unconditional **(Call Forwarding Unconditional [CFU])**
– When your extension is busy **(Call Forwarding Busy [CFB])**
– When you do not answer **(Call Forwarding No Reply [CFNR])**

To set

PT/SLT/PS



To cancel

PT/SLT/PS



With Compliments
Absolute Phone & Data

To confirm the condition



With Compliments
Absolute Phone & Data

1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only)

Your PBX can provide you with answering machine service if an SVM card is installed.
Your extension is assigned a message box, into which callers can leave voice messages for you.
After callers reach your message box, they will hear your personal greeting message. You can record two kinds of personal greetings: a normal greeting message and a greeting message for each time mode. You can also play back and clear your greeting messages and the voice messages left by callers.

- Recording a Normal Greeting Message
- Recording a Greeting Message for Each Time Mode
- Redirecting Your Calls to Your Message Box
- Leaving Voice Messages
- Listening to Voice Messages Left by Callers
- Accessing Your Message Box from an Outside Telephone
- Accessing the Message Box of Another Extension from Your Extension

- You may hear a busy tone when trying to access your message box if too many other users are already accessing their message boxes. In that case, wait a few minutes and try again.
- If the used recording space (including greeting messages and voice messages left by callers) for the SVM card reaches a certain limit, the display informs you that the recording space is almost full, and you will hear dial tone 3 when going off-hook.

Dial Tone 3

With Compliments
Absolute Phone & Data

Recording a Normal Greeting Message

To record

PT/SLT/PS



To play back

PT/SLT/PS



To clear

PT/SLT/PS

With Compliments
Absolute Phone & Data

Recording a Greeting Message for Each Time Mode

In addition to a normal greeting message, you can record a specific greeting message for each time mode (day/lunch/break/night).

To record



To play back



With Compliments Absolute Phone & Data

To clear

PT/SLT/PS



- If both the greeting message for a certain time mode and the normal greeting message have been recorded, callers will hear the greeting message for that time mode. However, if no greeting message has been recorded for a certain time mode, the normal greeting message will be played instead.

Redirecting Your Calls to Your Message Box

You can set incoming calls to be redirected to your own message box so that callers can leave voice messages when you cannot answer the phone.

To set/cancel

PT/SLT/PS



With Compliments Absolute Phone & Data

- The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

Leaving Voice Messages

If the extension user you called is not able to answer your call, and your call is redirected to the message box, you will hear the greeting message. Then, you can leave a voice message for that extension. It is also possible to leave a voice message directly in the message box of a desired extension by following the steps below:

To leave a voice message directly to another extension's message box



- Voice message recording will stop, you will hear a notification tone, and the call will be disconnected, in the following cases:
  - **a.** the recording time for the voice message reaches the preprogrammed limit. (default: 120 seconds)
  - **b.** the recording space for the SVM card reaches the limit.

- When you are on the phone, you can transfer the call directly to the message box of a desired extension by placing the call on hold temporarily, then pressing ✳38 + #6 + the desired extension number. This allows the caller to leave a voice message in the message box of the desired extension.

With Compliments Absolute Phone & Data

Listening to Voice Messages Left by Callers

When a caller leaves a voice message, information about that caller is also recorded as the SVM Log. The SVM Log can be viewed using the display of a PT or PS by pressing the Message button.

To listen to voice messages

PT/PS

While on-hook

Press **MESSAGE** until **desired SVM Log** appears.

Off-hook.

PT/SLT/PS



Off-hook.

Enter ✱**38**.

Enter **3**.

PT/SLT/PS

Off-hook.

Press **MESSAGE** or enter ✱**702**.

With Compliments
Absolute Phone & Data

- In addition to the caller information that is recorded in the Call Log, the following SVM Log information is recorded with voice messages left by callers:
  - Caller's Name
  - Caller's Telephone Number
  - Time recording started
  - Voice Message Status
    - "New" is displayed for voice messages that have not previously been listened to.
    - "Old" is displayed for voice messages that have previously been listened to.
- You can lock the SVM Log display by using an extension PIN (Personal Identification Number) to prevent other users from viewing the information and from playing back your voice messages (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If your telephone has a Message for Another Extension button, you can access the message box of another extension and listen to voice messages for that extension.
- If a new voice message has been left in your message box, you will hear dial tone 4 after going off-hook. In addition, if your telephone has a Message button or Message/Ringer Lamp, the corresponding button or lamp will light when a voice message has been left.
  Dial Tone 4

- The following operations are available by entering the corresponding number while you hear the recorded voice message.
  - 1: To play back the voice message from the beginning (without a confirmation tone)
  - 2: To go to the next voice message
  - 3: To clear the voice message
    (Press the AUTO DIAL/STORE button or enter 1 to confirm.)
  - 4: To call back the caller who left the voice message
  - 5: To go back to the previous voice message
  - #6: To leave a voice message directly in the message box of another extension
    (Enter desired extension number.)
  - #8: To play back your greeting message and record a voice message in your own message box
  - #9: To end the call
  - #✳: To play back the voice message from the beginning (with a confirmation tone)

With Compliments
Absolute Phone & Data

To listen to voice messages while your display is locked



- When you press the Message button while on-hook to play back voice messages, Display Lock is temporarily deactivated.

To clear voice messages



With Compliments
Absolute Phone & Data

Accessing Your Message Box from an Outside Telephone

You can remotely access your message box and perform any operations of the SVM feature through an outside line as if you were at your own extension.


From Outside Telephone
PIN: Personal Identification Number
desired phone no.
The greeting message is played back.
✳ 4 7
Off-hook.
Dial desired phone number of a destination that has set the SVM feature.
Enter ✳47 while hearing the greeting message.
your extension no.
extension PIN
C.Tone & D.Tone
✳ 3 8
You can perform any of the operations by following the steps in this section.
Dial your extension number.
Enter extension PIN (max. 10 digits).
Enter ✳38.

- If you hear a reorder tone when you try to leave a voice message directly in the message box of another extension, that message box is unavailable. You can enter another extension number by pressing "✳".
- When accessing your message box from an outside telephone, you cannot call back callers who have left voice messages, by pressing 4 while hearing the voice message.

To listen to voice messages left in the message box of another extension



With Compliments Absolute Phone & Data

Accessing the Message Box of Another Extension from Your Extension

You can access the message box of another extension (for example, to record a greeting message for that extension) by following the steps below:


PT/SLT/PS
PIN: Personal Identification Number
Off-hook.
Enter ✱47.
desired extension no.
Dial desired extension number.
extension PIN
C.Tone & D.Tone
Enter ✱38.
You can perform any of the operations by following the steps in this section.
Enter extension PIN for that extension (max. 10 digits).
If the wrong extension PIN is entered, you hear an alarm tone.

With Compliments
Absolute Phone & Data

1.5.3 Showing a Message on the Caller's Telephone Display (Absent Message)

You can show the reason you do not answer, if the caller uses a Panasonic display proprietary telephone. There are eight preprogrammed messages and one for your personal message (16 characters). The selected message is shown on the display of your telephone.

Message no.	Message (Example)
1	`Will Return Soon`
2	`Gone Home`
3	`At Ext %%%%` (Extension number)
4	`Back at %%:%%` (Hour:Minute)
5	`Out until %%/%%` (Month/Day)
6	`In a Meeting`
7	
8	
9	*A message assigned for each extension. (Personal Absent Message)*

With Compliments Absolute Phone & Data

To set



To cancel



- Enter the desired value in the "%" positions. You must enter the correct number of characters as represented by the "%" using 0 to 9 or ✳.
- The default messages can be changed. Consult your dealer.
- To create your personal message (Message no. 9), refer to "3.1.2 Settings on the Programming Mode".

With Compliments
Absolute Phone & Data

1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)

You can lock your extension so that other users cannot make inappropriate outside calls. This feature is also known as Electronic Station Lockout.

To lock

PT/SLT/PS

Off-hook. Enter ✱77. Enter **1**. On-hook.

To unlock

PT/SLT/PS ***PIN: Personal Identification Number***

Off-hook. Enter ✱77. Enter **0**. Enter **extension PIN** (max. 10 digits). On-hook.

With Compliments
Absolute Phone & Data

- **If you forget the extension PIN or cannot unlock your extension,** consult your manager. He can clear your extension PIN. Then, you can set the new PIN and unlock your extension by entering it.
- If your extension is locked by this feature, it cannot perform features as follows:
  - Making outside calls
  - Changing the call forwarding destination
- If you do not set extension PIN, you cannot lock and unlock your extension.

To make an outside call while your extension is locked

PT/SLT/PS ***PIN: Personal Identification Number***



Off-hook. Enter ✱47. Dial **your extension number**. Enter **extension PIN** (max. 10 digits). Dial **desired phone number.**

If the wrong extension PIN is entered, you hear an alarm tone.

Seize outside line before entering outside phone number.

- After you make an outside call, Extension Dial Lock is automatically activated again.

With Compliments
Absolute Phone & Data

1.6 Making/Answering an Announcement

1.6.1 Paging

- Group Paging
- Paging and then Transferring a Call

Group Paging

You can make a voice announcement to proprietary telephones or external speakers or both in the preset group simultaneously.

To page

PT/SLT/PS



- If the group which you paged is already being used for paging, you hear a busy tone.

Paging and then Transferring a Call

PT/SLT/PS

During a conversation



With Compliments Absolute Phone & Data

- After you go on-hook, the caller can talk to the person who answers the page.

With Compliments
Absolute Phone & Data

1.6.2 Answering/Denying a Paging Announcement

To answer



To allow/deny a paging announcement (Paging Deny)



- The following are extensions that cannot receive a paging announcement:
  - Portable station
  - Single line telephone
  - Proprietary telephone that is ringing or busy
  - Proprietary telephone in Paging Deny mode
  - Proprietary telephone in DND mode
- Even if the announcement is not paging your extension, you can answer it, if it is paging your group.

With Compliments
Absolute Phone & Data

1.6.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)

You can call multiple parties assigned in the group and make a voice announcement. You can also establish a multiple party conversation with called parties. This conversation will be heard by other called parties. Called parties can listen to the announcement simply by going off-hook. They can send a notification tone if they want to join the conversation.

To make/answer a broadcasting call



◆ **For a caller**

To make a conversation with a specific party



With Compliments Absolute Phone & Data

To make a conversation with a party in the group's preassigned order

PT

During an announcement

Press **CONF**.

To end a conversation with a specific party

PT

During a conversation

● ***To end a conversation with a specific party***

Press **DSS**.

● ***To end a conversation with the party who joined the conversation last***

Press **TRANSFER**.

● ***To disconnect the party who joined the conversation last from the broadcast***

Press **FLASH/RECALL**.

With Compliments
Absolute Phone & Data

- In this case, the FLASH/RECALL button must be in Flash/Recall mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.

◆ For a called extension

To send a notification tone to the caller and join a conversation



- A conversation can be established with a maximum of 4 parties (including the caller).

With Compliments Absolute Phone & Data

1.7 Setting the Telephone According to Your Needs

1.7.1 Setting the Alarm (Timed Reminder)

You can receive an alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The alarm can occur either once or daily (every day until cancelled) at a preset time. When you go off-hook to answer, you will hear a special dial tone or prerecorded message.

To set



To cancel



To stop or answer the ringback



With Compliments
Absolute Phone & Data

To confirm

PT

Press **TRANSFER** several times.

- You can also confirm the Timed Reminder by using the soft button.
- The alarm keeps ringing for preprogrammed seconds.
- **If you receive an incoming call during ringback,** the ringing starts after the ringback stops.
- **If you are having a conversation exceeding alarm ringing period,** the ringback will start after your conversation.

With Compliments
Absolute Phone & Data

1.7.2 Refusing Incoming Calls (Do Not Disturb [DND])

You may set this feature when you are in a meeting or busy.

To set/cancel



- When using a proprietary telephone, you can set or cancel Do Not Disturb by pressing the FWD/DND button (fixed button) instead of "✳710".

- The FWD/DND button light shows the current status as follows:
  Off: Both features are not set.
  Red on: FWD mode
  Flashing red slowly: DND mode
- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

  (1) When in the FWD/DND Cycle Switch Mode:
  Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:

  (2) When in the FWD/DND Setting Mode:
  Pressing the FWD/DND button (fixed button) while in idle status will take you directly to the programming mode for the FWD/DND setting.
  (Refer to "3.1.2 Settings on the Programming Mode".)

  Note

  A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.
- If your extension has set this feature, a calling extension will hear DND tone.
- If this feature is set, the Call Forwarding (FWD) feature does not work.
- Specified extensions can override this feature and call DND extensions (DND Override).

With Compliments Absolute Phone & Data

- When intercom calls are set to be handled differently from outside calls (DND set/cancel), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, because:

  a) the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will indicate the setting for either outside calls or intercoms calls, but not both.

  Note

  The DND icon on PS display reflects the setting for outside calls only.

  b) pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will not change the FWD or DND mode for intercom calls and outside calls separately.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons.

With Compliments
Absolute Phone & Data

1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)

During a conversation, you can be informed of a call waiting with a tone or voice announcement through your built-in speaker or handset. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])

Call Waiting Tone:
a waiting tone through the built-in speaker of PT/handset of SLT. To change the tone from PT, refer to "3.1.2 Settings on the Programming Mode".
OHCA:
a voice announcement through the built-in speaker
Whisper OHCA:
a voice announcement through the handset

To set/cancel for intercom calls



To set/cancel for outside calls



With Compliments
Absolute Phone & Data

- OHCA is only available with certain digital proprietary telephones. For more details, consult your dealer.
- Whisper OHCA is only available with certain digital proprietary telephones and IP proprietary telephones. In addition, both you and the other party must use supported telephones. For more details, consult your dealer.

1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])

CLIP:
When making an outside call, you can present your preprogrammed telephone number to the called party.
COLP:
When receiving an outside call, you can present your preprogrammed telephone number to the calling party.

You can select the telephone number sent, either the number of the line used or the number assigned to your extension.
If you select "Public", the calling/called party sees the number of the line used (subscriber's number).
If you select "Your extension", they see the telephone number assigned on your extension.

To show either the number assigned to the outside line or your extension



- Availability of this feature depends on the ISDN service of your telephone company.

- If you use the ICD Group button to make a call to the other party, the telephone number assigned to the ICD Group will be used.

With Compliments Absolute Phone & Data

1.7.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])

When receiving an outside call, you can select whether the caller can see your telephone number or not.

To show/prevent



- You can change the mode by pressing a preset COLR button while on-hook. The COLR button light shows the current status as follows:
  Off: shows your telephone number.
  Red on: prevents your telephone number being displayed.
- Availability of this feature depends on the ISDN service of your telephone company.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Connected Line Identification Restriction (COLR) button.

With Compliments
Absolute Phone & Data

1.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

When making an outside call, you can select whether the called party can see your telephone number or not.

To show/prevent



- You can change the mode by pressing a preset CLIR button while on-hook. The CLIR button light shows the current status as follows:
  Off: shows your telephone number.
  Red on: prevents your telephone number being displayed.
- Availability of this feature depends on the ISDN service of your telephone company.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Calling Line Identification Restriction (CLIR) button.

With Compliments
Absolute Phone & Data

1.7.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)

PT/SLT/PS



Off-hook. Enter ✱733. Enter **1** to prevent or **0** to allow. On-hook.

- Some extensions may be prohibited from performing this feature.

With Compliments
Absolute Phone & Data

1.7.8 Turning on the Background Music (BGM)

You can listen to the background music through your telephone speaker while on-hook. An external music source, such as a radio, must be connected.
If your extension becomes busy (off-hook, making or receiving a call etc.), the music stops temporarily. When you go back on-hook, the music starts again.

To select and set/cancel

<For users of KX-TDA100/KX-TDA200>



<For users of KX-TDA30>



With Compliments Absolute Phone & Data

1.7.9 Protecting Your Line against Notification Tones (Data Line Security)

You can protect the line against audible notification tones, such as a call waiting tone during a conversation. Set this feature if your extension has a data communication device, such as a computer or fax machine connected to ensure secure data transmission.

To set/cancel

PT/SLT/PS



With Compliments
Absolute Phone & Data

1.7.10 Checking the Time Service Status

You can check the current status of the Time Service on the display.

PT

While on-hook



Press **TRANSFER** or **Time Service (Day/Night/Lunch/Break)**.

- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:
  Off: Day mode
  Green on: Lunch mode
  Flashing green: Break mode
  Red on: Night mode
  Flashing red: Holiday mode
- Any extension user except the managers can check the current status by pressing the Time Service (Day/Night/Lunch/Break) button.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Time Service (Day/Night/Lunch/Break) button.

With Compliments
Absolute Phone & Data

1.7.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone)

In the case where a single line telephone is connected in parallel to your digital proprietary telephone, you can choose whether the parallelled single line telephone will ring to an incoming call or not.
(Default: Ring)

DPT



- **Even if "No ring" is selected,** calls can be made and answered on the single line telephone by lifting the handset.
- **If you go off-hook while your parallelled telephone is in use,** the call will switch over to you.
- This feature is not available for the KX-T7665.

With Compliments
Absolute Phone & Data

1.7.12 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode)

Your PS can be used in parallel with a PT or SLT.
When in this mode, incoming calls to a wired telephone also ring the paired PS.

To set



To cancel



- Some wired telephones are prohibited from using this feature.
- **If you go off-hook while your parallelled telephone is in use,** the call will switch over to you.

With Compliments
Absolute Phone & Data

1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear)

You can reset the settings of the following features on your extension to the default settings with one operation.
This feature is also known as Station Programme Clear.

Features	Default Setting
Hot Line*	**Off**
Message Waiting—(All the messages that have been left by other extension users)	**Off**
Call Pickup Deny	**Allow**
Call Forwarding (FWD)*	**Off**
Absent Message	**Off**
Paging Deny	**Allow**
Timed Reminder	**Cleared**
Do Not Disturb (DND)*	**Off**
Call Waiting for intercom calls* Call Waiting for outside calls*	**Disable (No call)** **Disable (No tone)**
Executive Busy Override Deny	**Allow**
BGM	**Off**
Data Line Security	**Off**
Parallelled Telephone	**The telephone in parallel rings.**
Log-in/Log-out	**Log-in**

* These features may not be reset depending on the system programming.

With Compliments
Absolute Phone & Data

PT/SLT/PS

Off-hook. Enter ✱790. On-hook.

- For Users in Canada Only:
  After performing Extension Feature Clear, the setting of Call Waiting becomes "Enable (Tone)". In this case, dial tone 2 will be heard when you go off-hook.

1.8 Utilising the Call Centre

1.8.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)

You can control your status in an incoming call distribution group. When in the Log-out mode, incoming calls to the group will not ring at your extension. When you return, calls will again ring at your extension. (Default: Log-in)
Even if your extension is logged-in, you can have a specified time period (wrap-up time) when you will not receive calls after completing a previous call. This time can be used for you to write a report and so on.
You can also manually select "Not Ready" mode to temporarily leave a distribution group.



To set Log-in/Log-out

PT/SLT/PS *ICD Group: Incoming Call Distribution Group*



With Compliments
Absolute Phone & Data

PT/PS *ICD Group: Incoming Call Distribution Group*

While on-hook



Press **Log-in/Log-out**. Enter **ICD Group extension number** or ✱.

PT/PS

While on-hook



Press **Log-in/Log-out of a specified group**.

To enter/leave the Not Ready mode

PT/SLT/PS



Off-hook. Enter ✱735. Enter **1** or **0**. On-hook.

To set/cancel the Not Ready mode or to leave the Wrap-up mode (To enter the Ready mode)

PT/PS

While on-hook

Press red or flashing red **Wrap-up.***

With Compliments Absolute Phone & Data

- * The status will be as follows:
  Ready → Not Ready
  Not Ready → Ready
  Wrap-up → Not Ready
- The Log-in/Log-out of a specified group button light shows the current status as follows:
  Off: Log-in mode
  Red on: Log-out mode
- The Wrap-up button alternates the setting of Wrap-up mode, Not Ready mode or Ready mode.
  The Wrap-up button light shows the current status as follows:
  Off: Ready mode
  Red on: Not Ready mode
  Flashing red: Wrap-up mode
- In Wrap-up mode/Not Ready mode, your extension does not receive calls through any group, even if it belongs to multiple groups.
- There may be at least one extension in the incoming call distribution group that is in the Log-in mode.
- The Supervisor extension can control the Log-in/Log-out status of other extensions.
  For more information, refer to "1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)".

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Log-in/Log-out button, a Log-in/Log-out of a specified group button or a Wrap-up button.

With Compliments
Absolute Phone & Data

1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)

– Monitoring the Status of Waiting Calls
– Monitoring and Changing the Log-in/Log-out Status of Extensions

The extension assigned as a Supervisor extension can monitor and control the status of other extensions in an incoming call distribution group. It should have a PT with 6-line display. The display and DSS buttons show as follows:



With Compliments Absolute Phone & Data

Monitoring the Status of Waiting Calls

The Supervisor extension can monitor the status of calls waiting to be answered in the queue. If an incoming call distribution group has an overflowed call, the display shows the status automatically.
The following information is displayed.

<Queuing Monitor>

- The current date/time
- The ICD Group extension number/name
- The number of waiting calls
- The longest waiting time

<Call Log History>

- The date/time when cleared at last time
- The total number of received calls
- The number of overflowed calls
- The number of unanswered calls
- The average waiting time of queuing calls

To monitor

Display PT *ICD Group: Incoming Call Distribution Group*

Off-hook. Enter ✱739. Enter **ICD Group extension number**. On-hook.

To clear Call Log History

Display PT

Press "**LOG**". Press "**CLEAR**".

- The accumulated data is cleared.
"*****" shows if the number to be displayed exceeds the maximum displayable digits.

Monitoring and Changing the Log-in/Log-out Status of Extensions

The Supervisor extension can monitor the Log-in/Log-out status of the incoming call distribution group members by the DSS button light. It can also change their Log-in/Log-out status if needed.

To monitor

Display PT

After viewing the status of waiting calls

Press "**SPRVS**".

With Compliments
Absolute Phone & Data

To change the Log-in /Log-out mode

Display PT

Press desired **DSS**.

- The DSS button light shows the current status as follows:
  Off: The extension is not in the group.
  Green on: Log-in (Ready) mode
  Flashing green: Log-in (Not Ready) mode
  Red on: Log-out mode

With Compliments
Absolute Phone & Data

1.8.3 Forwarding a Waiting Call (Manual Queue Redirection)

When your incoming call distribution group is busy and other outside calls arrive, the arriving calls are put in a waiting queue.
Extensions can check the status of the queue with the Hurry-up button light, and forward the longest waiting call in the queue to a preset destination manually.
This feature is also known as Hurry-up Transfer.

To forward the waiting call

PT/PS

Press red or flashing red **Hurry-up**.

- The Hurry-up button light shows the current status as follows:
  Off: No waiting call.
  Red on: Some calls are waiting.
  Flashing red: The number of calls exceeds the manual queue redirection level.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Hurry-up button.

With Compliments
Absolute Phone & Data

1.9 Using User-supplied Equipment

1.9.1 If a Doorphone/Door Opener is Connected

You can talk to a person at the door through the doorphone. Preprogrammed extensions or an outside party can receive the calls from the doorphone. You can open the door.

– Doorphone Call
– Opening a Door (Door Open)

Doorphone Call

To call from the doorphone



To answer a call from the doorphone

To call the doorphone



- If no one answers a doorphone call within a specified time period, the call is cancelled.

With Compliments
Absolute Phone & Data

Opening a Door (Door Open)

Some extensions may be prohibited from using this feature.

From a specified extension

PT/SLT/PS



Off-hook. Enter ✱55. Enter **doorphone number** (2 digits). On-hook.

From any extension while talking to the doorphone

PT/SLT/PS

Enter **5**. On-hook.

- The door open will be triggered for a specified time period.

With Compliments
Absolute Phone & Data

1.9.2 If an External Relay is Connected

Preprogrammed extensions can switch on a relay (e.g., alarm) connected to the PBX.

To switch on the relay

PT/SLT/PS



- The relay will be switched off after a specified time period.

With Compliments
Absolute Phone & Data

1.9.3 If an External Sensor is Connected

Preprogrammed extensions can receive an alert call from an external sensor (e.g., security alarm) connected to the PBX.

To answer a sensor call



- If you do not answer a sensor call within a specified time period, the sensor call will stop.

With Compliments
Absolute Phone & Data

1.9.4 If a Host PBX is Connected

– Accessing External Services (External Feature Access [EFA])

Accessing External Services (External Feature Access [EFA])

You can access special features (e.g., Call Waiting) offered by a host PBX or telephone company. This feature is only effective for an outside call.

<Example> To hold the current call and then talk to the new party



- In this case, the FLASH/RECALL button on a proprietary telephone must be in External Feature Access (EFA) mode. For information about setting the mode of your FLASH/RECALL button, consult your dealer.
- Regarding the service code, consult your dealer.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit an External Feature Access (EFA) button.

With Compliments Absolute Phone & Data

1.9.5 If a Voice Processing System is Connected

You or an outside party can access the Voice Processing System from a telephone.

– Call Forwarding to Voice Mail (Voice Mail Integration)

If your PBX has a Panasonic Voice Processing System connected (e.g., KX-TVP/KX-TVS series) using digital integration, the following features are also available:

– Screening Calls (Live Call Screening [LCS])
– Recording a Conversation

Call Forwarding to Voice Mail (Voice Mail Integration)

– To forward your calls to your mailbox
– To transfer a call to a mailbox
– To listen to messages

If you cannot answer calls, you can forward them to your mailbox. You can select the type of incoming calls (Intercom Calls/Outside Calls/Both Calls) that are forwarded.
If your telephone has a Message button, the Message light turns on when a message is left in your mailbox. You will hear an indication tone* when going off-hook, regardless of whether or not your telephone has a Message button.
You can also transfer received outside calls to a mailbox so that calling parties can leave messages. If you create a Voice Mail Transfer button on your phone, the transfer is done without knowing the mailbox number (Voice Mail Transfer).
The duration for recording depends on the voice processing system.

To forward your calls to your mailbox



With Compliments Absolute Phone & Data

To transfer a call to a mailbox

PT/PS

During a conversation



Press **Voice Mail Transfer**.

Press **DSS** or dial **desired extension number**.

To listen to messages

PT/SLT/PS



Off-hook.

Press **MESSAGE** or enter **voice mail floating extension number**.

- *Indication tone after going off-hook

- You can access a voice mail with one touch.

- The default voice mail floating extension number is 500.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Voice Mail Transfer button or a Message button.

With Compliments
Absolute Phone & Data

Screening Calls (Live Call Screening [LCS])

While a caller is leaving a message in your mailbox, you can monitor the call without answering. If you so desire, you can answer the call while monitoring. There are two methods available (Default: Hands-free mode).

Hands-free mode:
You can monitor the message automatically, live through the telephone speaker.
Private mode:
You will hear an alarm tone while the caller is leaving a message.

Before operating

- Create a Live Call Screening (LCS) button (Personal Programming).
- Select the mode, either Hands-free or Private (Personal Programming).
- Set the extension PIN (Personal Identification Number).
- Set the Live Call Screening feature.

To set Live Call Screening


PT/PS
PIN: Personal Identification Number
(Live Call Screening)
extension PIN
Press Live Call Screening.
Enter extension PIN (max. 10 digits).
This is required only when an extension PIN is stored.

To cancel Live Call Screening



With Compliments
Absolute Phone & Data

Operation Flowchart

The operations in the shaded areas can be done hands-free.



With Compliments Absolute Phone & Data

- The Live Call Screening (LCS) button light shows the feature status as follows:
  Off: LCS is off.
  Flashing green rapidly: Alerting in the Private mode.
  Flashing green slowly: Monitoring.
  Red on: LCS is on.
- The manager extension can clear an extension PIN.
- This feature is available for a single line telephone if it is connected to a proprietary telephone in parallel. (Private mode only)
  To answer the call while monitoring, press Recall/hookswitch.
- Only the handset monitoring in the Private mode is available for PS users.

Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Live Call Screening Mode Set**
  Select the mode, either monitoring the message through the speaker automatically or receiving, while the caller leaves a message.
- 3.1.3 Customising the Buttons
  Create or edit a Live Call Screening (LCS) button.

Recording a Conversation

You can record a conversation into a mailbox while talking on the phone.
You can select the mailbox each time you record a conversation.

To record into your mailbox (Two-way Record)

PT/PS

During a conversation



Press **Two-way Record**.

To record into another mailbox (Two-way Transfer)

PT/PS

During a conversation



Press **Two-way Transfer**.

Press **DSS** or enter **another extension number**.

To stop recording, press this button again.

With Compliments
Absolute Phone & Data

To record into another mailbox with one touch (One-touch Two-way Transfer)

PT/PS

During a conversation

Press **One-touch Two-way Transfer**.

- The Two-way Record button light, Two-way Transfer button light or One-touch Two-way Transfer button light shows the current status as follows:

  Off: Not recording.
  On: Recording the conversation.

- **Note:**
  When you record your Two-way telephone conversations, you should inform the other party that the conversation is being recorded.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Two-way Record button, a Two-way Transfer button and a One-touch Two-way Transfer button.

With Compliments
Absolute Phone & Data

1.10 After Moving to a New Location in the Office

1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension)

You can use the same features assigned on your previous extension even if you move to another extension in the office.
You can retain your settings, such as extension number or One-touch Dialling memory, on the new extension.
This feature is also known as Walking Station.

To set



- Your previous extension will receive the old settings of your new extension.
- This feature is not available for IP proprietary telephones.
- This feature is available for movement between SLT and SLT, PT and PT or SLT and PT.
- For more information, refer to "3.1.1 Customising Your Phone (Personal Programming)".

With Compliments Absolute Phone & Data

1.11 Using a Display Proprietary Telephone

1.11.1 Using the Call Log

This is available for display proprietary telephones and portable stations.

– Calling with the Incoming Call Log
– Calling with the Outgoing Call Log

Calling with the Incoming Call Log

When you receive an outside call or an external sensor call, call information is recorded automatically in the incoming call log. A preprogrammed number of calls can be logged per extension.
When the call log is full and other call arrives, the oldest call is deleted.
You can modify the logged telephone number.
When the Call Log button light turns on, there is a call which you did not answer.

The following information is logged.

- Caller's Name
- Date/Time call received
- Answered or Not Answered
  Confirmed or Not Confirmed
- Caller's Phone Number

With Compliments
Absolute Phone & Data

To confirm the log information with the Call Log button

Display PT

While on-hook

Press **Call Log** until **desired party** appears.

To confirm the log information with the Navigator Key

T7600

While on-hook

Press **Left** twice.

Press **Up** or **Down** until **desired party** appears.

To clear the log information

Display PT

While confirming the log information



Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Press **TRANSFER**.

To call

Display PT

While confirming the log information

Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Off-hook.

To store the caller's information in personal speed dialling

Display PT

While confirming the log information

Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Press **STORE**.

With Compliments
Absolute Phone & Data

- The Call Log button light shows the current status as follows:
  Off: No incoming call. Or you have already viewed the call log.
  Red on: You have missed calls to view.
- If your call is answered by another extension, the caller's information is recorded on the displays of both your extension and the answering extension.
- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- You can also have a Call Log button for an ICD Group (Incoming Call Distribution Group).
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.

Customising Your Phone

3.1.3 Customising the Buttons
Create or edit a Call Log button or Call Log for ICD Group button.

Calling with the Outgoing Call Log

You can redial using the outgoing call log.

To call

T7600

While on-hook

Press **Left**. → Press **Up** or **Down** until **desired number** appears. → Off-hook.

To call with the REDIAL button

Display PT

While on-hook



Press **REDIAL** to display the outgoing call log.* → Press **REDIAL** until **desired number** appears. → Off-hook.

- * System programming is required for this operation. Consult your dealer.
- This operation is available only for digital proprietary telephones with a display.

With Compliments
Absolute Phone & Data

To store the caller's information in personal speed dialling

Display PT

When the desired party is displayed

Press **STORE**.

- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.

With Compliments
Absolute Phone & Data

1.11.2 Using the Directories

You can call using the directories (*Personal Speed Dialling Directory, System Speed Dialling Directory and Extension Number Directory*).
Only personal directories can be stored, edited or deleted on your extension.
If a call arrives while you are using a directory, the display will be replaced with the caller's information.

– Calling with the Directory
– Storing Names and Numbers
– Entering Characters

Calling with the Directory

To select and call

T7600

While on-hook

Press **Right** until **desired directory** appears.*

Press **Up** or **Down** until **desired party** appears.

Off-hook.

- * The display order is as follows:
  One time: Personal Speed Dialling Directory
  Two times: System Speed Dialling Directory
  Three times: Extension Number Directory
- To cancel or exit, press the CANCEL or FLASH/RECALL button.
- You can lock your personal speed dialling directory by using an extension PIN (Personal Identification Number), so that you can prohibit access to it (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".

- Directory entries generally should include name and number. If the name is not registered, an entry cannot be displayed.
- The System Speed Dialling Directory can be displayed simply by pressing the AUTO DIAL/ STORE button while on-hook.

To make an intercom call using Extension Number Directory when your telephone accesses an outside line automatically

T7600

While on-hook

Press **Right** three times.

Press **Up** or **Down** until **desired party** appears.

Press **INTERCOM**.

Off-hook.

With Compliments
Absolute Phone & Data

Storing Names and Numbers

To store a Personal Speed Dialling Directory item

Display PT

While on-hook



Enter **phone number** (max. 32 digits).

Press **ENTER** or **STORE**.

Enter **name** (max. 20 characters).

Press **ENTER** or **STORE**.

Press **PROGRAM** or **PAUSE**.

- Telephone numbers and names displayed are stored using the first spare Personal Speed Dialling memory available.
- For a PS user, refer to "Operating Instructions" for PS.

- For more details, refer to "To store the names and numbers in personal speed dialling" in "3.1.2 Settings on the Programming Mode".

With Compliments
Absolute Phone & Data

Entering Characters

You can enter the following characters. The tables show you the characters available for each button. Table 1 or Table 2 can be programmed.

Table 1 (Standard mode)

Times / Buttons	1	2	3	4	5	6	7	8	9
1	!	?	"	1					
2	A	B	C	a	b	c	2		
3	D	E	F	d	e	f	3		
4	G	H	I	g	h	i	4		
5	J	K	L	j	k	l	5		
6	M	N	O	m	n	o	6		
7	P	Q	R	S	p	q	r	s	7
8	T	U	V	t	u	v	8		
9	W	X	Y	Z	w	x	y	z	9
0	(Space)	.	,	'	:	;	0		
*	/	+	–	=	<	>	*		
#	$	%	&	@	(	)	€	£	#

With Compliments
Absolute Phone & Data

Table 2 (Option mode)

Times / Buttons	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	!	?	"	ä	ö	ü	1								
2	A	B	C	a	b	c	À	Á	Â	Ã	Ä	Å	Æ	Ç	2
3	D	E	F	d	e	f	Đ	È	É	Ê	Ë	3			
4	G	H	I	g	h	i	Ì	Í	Î	Ï	4				
5	J	K	L	j	k	l	5								
6	M	N	O	m	n	o	Ñ	Ò	Ó	Ô	Õ	Ö	Ø	Œ	6
7	P	Q	R	S	p	q	r	s	Š	ß	7				
8	T	U	V	t	u	v	Ù	Ú	Û	Ü	8				
9	W	X	Y	Z	w	x	y	z	Ý	Ž	9				
0	(Space)	.	,	'	:	;	0								
*	/	+	–	=	<	>	*								
#	$	%	&	@	(	)	€	£	#						

With Compliments
Absolute Phone & Data

Table 2 (Option mode for CE model)

Times / Buttons	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	!	?	"	ä	ö	ü	1								
2	A	B	C	a	b	c	Á	Â	Ă	Ä	Ą	Ć	Ç	Č	2
3	D	E	F	d	e	f	Ď	Đ	É	Ę	Ë	ě	3		
4	G	H	I	g	h	i	Í	Î	4						
5	J	K	L	j	k	l	Ľ	Ĺ	5						
6	M	N	O	m	n	o	Ń	Ň	Ó	Ô	Õ	Ö	6		
7	P	Q	R	S	p	q	r	s	Ŕ	Ř	Š	Ś	Ş	ß	7
8	T	U	V	t	u	v	Ť	Ţ	ů	Ú	Ű	Ü	8		
9	W	X	Y	Z	w	x	y	z	Ž	Ź	Ż	ý	9		
0	(Space)	.	,	'	:	;	0								
*	/	+	—	=	<	>	*								
#	$	%	&	@	(	)	€	£	#						

With Compliments
Absolute Phone & Data

Table 2 (Option mode for GR model)

Times / Buttons	1	2	3	4	5	6	7	8	9
1	!	?	"	1					
2	A	B	Γ	2					
3	Δ	E	Z	3					
4	H	Θ	I	4					
5	K	Λ	M	5					
6	N	Ξ	O	6					
7	Π	P	Σ	7					
8	T	Y	Φ	8					
9	X	Ψ	Ω	9					
0	(Space)	.	,	'	:	;	0		
*	/	+	−	=	<	>	*		
#	$	%	&	@	(	)	€	£	#

With Compliments
Absolute Phone & Data

Table 2 (Option mode for RU model)

Times / Buttons	1	2	3	4	5	6	7	8	9	10	11
1	А	Б	В	!	?	"	1				
2	Г	Д	Е	Ё	2						
3	Ж	З	И	Й	3						
4	К	Л	М	4							
5	Н	О	П	5							
6	Р	С	Т	6							
7	У	Ф	Х	7							
8	Ц	Ч	Ш	8							
9	Щ	Ъ	Ы	Ь	9						
0	Э	Ю	Я	(Space)	.	,	'	:	;	0	
*	/	+	–	=	<	>	Ґ	Є	І	Ї	*
#	$	%	&	@	(	)	€	І	Ў	#	

With Compliments
Absolute Phone & Data

1.11.3 Accessing System Features (System Feature Access)

You can access a feature with the "Feature Access" menu.

To access "Feature Access" menu and select the feature



Features	Refer to
Automatic Callback Busy Cancel	1.2.4 When the Dialled Line is Busy or There is No Answer
Group Call Pickup	1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)
Directed Call Pickup	1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)
Doorphone Call	1.9.1 If a Doorphone/Door Opener is Connected
Door Open	1.9.1 If a Doorphone/Door Opener is Connected
External Background Music	2.1.4 Turning on the External Background Music (BGM)
Paging	1.6.1 Paging

With Compliments
Absolute Phone & Data

Section 2

Manager Operation

This chapter shows the manager how to control the other extensions or the PBX.

With Compliments
Absolute Phone & Data

2.1 Control Features

2.1.1 Extension Control

The manager extension can control the settings of other extensions.

– Changing the Settings of Other Extensions

Changing the Settings of Other Extensions

To lock/unlock other extensions (Remote Extension Dial Lock)

This feature is also known as Remote Station Lock Control.



- The manager can use Remote Extension Dial Lock to unlock any extension, whether that extension was locked remotely (Remote Extension Dial Lock) or from the extension itself (Extension Dial Lock).

With Compliments
Absolute Phone & Data

2.1.2 Time Service Mode Control

The manager extension or the preprogrammed extension can change the time mode (Day, Lunch, Break or Night).
There are two methods (Automatic or Manual) of changing the time modes.
Automatic: enables the time mode for each day of the week to change automatically. You may also change it manually.
Manual: enables to change a mode in manual as follows.

To change the time mode (Day/Night/Lunch/Break)

PT/PS

While on-hook

Press **Time Service (Day/Night/Lunch/Break)** until the desired mode appears.

PT/SLT/PS



Off-hook. Enter ✱780. Enter **0** to **3** as you desire. On-hook.

To select the time service switching mode (Automatic/Manual)

PT/PS

While on-hook

Press **Time Service Switching Mode (Automatic/Manual)**.

With Compliments Absolute Phone & Data

- Besides the time mode, there is Holiday mode. It can change mode once on a specified date.
- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:

  Off: Day mode
  Green on: Lunch mode
  Flashing green: Break mode
  Red on: Night mode
  Flashing red: Holiday mode
- The Time Service Switching Mode (Automatic/Manual) button light shows the current status as follows:

  Off: Automatic
  Red on: Manual

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Time Service (Day/Night/Lunch/Break) button or a Time Service Switching Mode (Automatic/Manual) button.

With Compliments
Absolute Phone & Data

2.1.3 Restriction Level Control (Dial Tone Transfer)

The manager extension can change the restriction level, permitting an extension to make a call.

PT/PS

During a conversation with an extension



Press **Toll Restriction/ Call Barring**.

C.Tone

On-hook.

The extension can hear the dial tone and then make a call.

- The restriction level is changed to the preprogrammed level of Toll Restriction/Call Barring button.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Toll Restriction/Call Barring button.

With Compliments
Absolute Phone & Data

2.1.4 Turning on the External Background Music (BGM)

The manager extension can select and broadcast background music in the office through external speakers.

To select and start/stop the background music

<For users of KX-TDA100/KX-TDA200>



<For users of KX-TDA30>



With Compliments
Absolute Phone & Data

2.1.5 Recording Outgoing Messages (OGM)

The manager extension can record three kinds of greeting messages (OGM) as follows:

1. **DISA message**: Used to greet and guide callers so that they access extension group or outside party without operator assistance.
2. **Incoming Call Distribution Group message**: Used to greet and guide callers to an incoming call distribution group.
3. **Timed Reminder message**: Used for a wake-up call message when the extension answers the Timed Reminder.

All messages have their own extension numbers. You can select the desired message. You have two methods for recording a message. One is recorded using the handset, and the other is recorded from an external BGM (MOH) port.

To record



To play back



With Compliments Absolute Phone & Data

To record from an external BGM (MOH) port

<For users of KX-TDA100/KX-TDA200>



<For users of KX-TDA30>



With Compliments Absolute Phone & Data

To clear the message



- Record voice messages only; avoid the recording of music.

- The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

With Compliments
Absolute Phone & Data

2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)

When a problem is found on a certain outside line, the PBX automatically makes it unavailable for use temporarily. The manager can manually enable the outside line and allow users to use it again.

To re-enable an outside line

PT/SLT/PS



Off-hook. Enter ✳**785**. Enter **outside line number** (3 digits). On-hook.

- In some countries/areas, the PBX may not be able to automatically make a faulty outside line unavailable for use. Consult your dealer.

With Compliments
Absolute Phone & Data

2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features)

The hotel operator can check in or check out guests from his extension. When the hotel operator presses a flexible button assigned as "Check-in" or "Check-out" on his extension, the extension will switch to Room Status Control mode, and DSS button lights will show the current room status of extensions. Other features can also be used in a hotel-type environment.

– Check-in
– Check-out
– Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)
– Recording room information using a room extension

- The hotel operator must be using a 6-line display PT.
- Each DSS button light shows the current status as follows:
  Off: Check-out
  Red on: Check-in
- While in Room Status Control mode, the hotel operator extension is considered to be busy.
- While in Room Status Control mode, the display, INTERCOM button, and flexible buttons do not operate for other telephone features.
- Some of the operations in this section require system programming. Consult your dealer.

Check-in

The hotel operator can change the room status of extensions to check-in by using the Check-in button assigned on his extension.

To check in

Display PT

While on-hook



Press **Check-in**.

Dial **extension number** and then press **"ENTER"**, or press desired **DSS**.

Press **"YES"**.

Press **"EXIT"** or **Check-in**.

- After check-in, Remote Extension Dial Lock is deactivated, and the guest can make outside calls from the room extension. (Refer to "2.1.1 Extension Control".)
- After check-in, all billing data previously charged to the extension will be cleared automatically.
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
  <Example>

Date	Time	Ext	CO	Dial Number
02/02/00	03:07PM	1234		Check in

With Compliments Absolute Phone & Data

Check-out

The hotel operator can change the room status of extensions to check-out by using the Check-out button assigned on his extension.
Depending on the setting of the PBX, the hotel operator can do the following:

- Record/edit charges for Minibar/Others
- Print out an invoice containing charge information

Consult your dealer.

To check out a room with/without printing an invoice



With Compliments
Absolute Phone & Data

To record/edit room charges and check out a room with/without printing an invoice

Display PT

While on-hook



With Compliments
Absolute Phone & Data

- After check-out, Remote Extension Dial Lock is activated, and outside calls from the room extension are restricted. (Refer to "2.1.1 Extension Control".)
- After check-out, features set on the room extension will be reset to the default settings. For features that are reset, refer to "1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear)".
- After check-out, wake-up call and Call Log information for the room extension will be cleared automatically.
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
  <Example>

```
Date      Time      Ext     CO    Dial Number
-------------------------------------------------
02/03/00  08:08AM  1234          Check out
```

- To print out an invoice, a printer should be connected to the PBX. If the room extension is in use, an invoice cannot be printed out.
  <Example>

```
**************************************
*                Hotel               *
**************************************
Check in  : 01.JAN.00 06:31PM
Check out : 03.JAN.00 07:03AM
Room      :  202 : Mr. Smith

01/01/00 06:52PM  202 01 Call amount:0012  01:24'30 00084.50 001
02/01/00 06:07PM  202 01 123456789         00:10'12 00010.20 1234567890
02/01/00 07:30PM  202 01 012345678901234   00:06'36 00006.60 12345
02/01/00 08:45PM  202 01 0011234567890123  00:03'00 00003.00 12345

Telephone                  104.30 (Tax   10.000% =    9.48)
Minibar                      4.00 (Tax   10.000% =    0.36)
Others                       0.00 (Tax   15.000% =    0.00)
-------------------------------------------------------------
Total                FR    108.30 (Tax Total     =    9.84)

Sheet : 002

======= Hotel TDAPBX =======
Tel: +41 3 12 34 56 78  Fax: +41 3 12 34 56 78
E-Mail: 12345678@hoteltdapbx.ch
```

With Compliments
Absolute Phone & Data

- The PBX can store a limited amount of room information. When this storage becomes almost full, the information of the extension that made the most calls is printed out automatically. In this case, the printout is similar to the example above, but without categorised charge information and the total. The PBX can then store new room information.
  "Call amount:0012" in the example above indicates that the information of 12 phone calls has previously been printed out automatically.

Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)

The hotel operator can remotely set/cancel a Timed Reminder to a room extension. He can also confirm the current setting.

To set



To cancel



To confirm



With Compliments Absolute Phone & Data

- Timed Reminder can also be set from the room extension. (For information about setting Timed Reminder, refer to "1.7.1 Setting the Alarm (Timed Reminder)".) The most recent setting will be valid no matter which extension made the setting.
- When a Timed Reminder starts, and when it is answered or not answered, detailed Timed Reminder information is recorded automatically. This requires system programming.
<Example>

Date	Time	Ext	CO	Dial Number
02/02/00	02:45PM	1234		Timed Reminder/Start
02/02/00	02:46PM	1234		Timed Reminder/No Answer
02/02/00	02:47PM	1234		Timed Reminder/Answer

Recording room information using a room extension

Room information can be recorded from a room extension using up to 8 preprogrammed messages (1-8). Depending on the content of the messages, a variety of information can be recorded. For a list of preprogrammed messages, consult your dealer.

To record

PT/SLT

Off-hook. ▶ ✳ 7 6 1 ▶ message no. ▶ parameter ▶ # ▶ C.Tone ▶ On-hook.

Off-hook. Enter ✳761. Enter **message number** (1-8). Enter **parameter** if required.* Enter #. On-hook.

- * If you see "%" signs, you are required to enter a parameter. Enter values in the "%" positions using 0 to 9 or ✳.
- <Example>
If "Snack %%.%%" has been programmed as message number 1 (for recording charges for room snacks consumed), hotel employees would enter data as in the example below using the room extension:

✳ 761 1 (message no.) 0300 (parameter (Snack charge)) #

Data similar to the example below is recorded.

Date	Time	Ext	CO	Dial Number
02/02/00	10:45AM	1234		Snack 03.00

- Any charges recorded here are not related to charges that the hotel operator records when checking out a room.

With Compliments Absolute Phone & Data

2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor

NDSS buttons can be customised on any extension connected to your PBX. An NDSS button allows an extension user to monitor another extension connected to another PBX in a private network. The NDSS button light shows the current status of the monitored extension in the same way as a DSS button. When it becomes unnecessary to monitor an extension connected to another PBX, the manager can stop the PBX from monitoring it. Any NDSS buttons set to monitor that extension will also stop monitoring.



- To restart monitoring of an extension after performing this operation, go off-hook, press the corresponding NDSS button, and go on-hook.

Customising Your Phone

- 3.1.3 Customising the Buttons
  Create or edit a Network Direct Station Selection (NDSS) button.

With Compliments
Absolute Phone & Data

With Compliments
Absolute Phone & Data

Section 3

Customising Your Phone & System

This chapter shows you how to customise your individual telephone or PBX according to your needs. Find the desired setting and program as necessary.

With Compliments
Absolute Phone & Data

3.1 Customising Your Phone (Personal Programming)

3.1.1 Customising Your Phone (Personal Programming)

You can customise your telephone features. For example, you can change the initial settings or button features according to your needs.

– Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])

- If you change your desk and extension, refer to "1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension)".

Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])

You can assign a password to each extension.
The following features require an extension PIN.

1. Screening calls (Live Call Screening [LCS])
2. Prohibiting other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box (Display Lock)
3. Using the same settings as your extension at other extensions (Walking Extension)
4. Remote Control Operation (Walking COS)
5. Extension Dial Lock Clear

With Compliments
Absolute Phone & Data

To set



To cancel

PT/SLT/PS *PIN: Personal Identification Number*



- **WARNING**
  There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).
  The cost of such calls will be billed to the owner/renter of the PBX.
  To protect the PBX from this kind of fraudulent use, we strongly recommend:
  a) Keeping your PIN secret.
  b) Selecting a complex, random PIN that cannot be easily guessed.
  c) Changing your PIN regularly.
- Valid numbers for an extension PIN are "0" through "9".
- If the wrong extension PIN is entered a preprogrammed number of times, the PIN is locked.
- If you forget your extension PIN or your extension PIN is locked, your manager can clear the extension PIN and extension PIN lock.

With Compliments
Absolute Phone & Data

3.1.2 Settings on the Programming Mode

You can programme features using the programming mode.

– Setting Features
– Clearing Features

- To exit at any time, lift the handset.
- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.

Setting Features

The default settings are shown in bold letters. For later reference, place a check mark in the boxes below to indicate your customised setting.

Notice

The default value may vary depending on country/area. For more details, consult your dealer.



With Compliments Absolute Phone & Data

Item	Programming Input	Selection & Parameter	
Your extension information	0 0	PT: The display shows the PBX number, slot number and port number. <example> EXT1050:10308 PBX no. Slot no. Port no. PS: The display shows the PS number. <example> EXT3001:99001 PS no.	
Preferred display contrast level from the 4 levels available (Display Contrast Selection)*1	0 1	1	☐ Light
		2	☐ Little Light
		3	☐ **Little Dark**
		4	☐ Dark

Item	Programming Input	Selection & Parameter	
Which display language do you prefer? (Display Language Selection)	0 2	1	☐ **English**
		2	☐ 2nd Language
		3	☐ 3rd Language
		4	☐ 4th Language
		5	☐ 5th Language
Would you like the call duration to be shown automatically on the display when answering an outside call? (Display Switching Mode)	0 3	0	☐ No—Manual (The display keeps showing all of the outside caller's information unless you change it to the call duration manually.)
		1	☐ **Yes—Automatic (The first line of the display will change to the call duration automatically when you answer an outside call.)**
Would you like to turn on the display backlight of the KX-T7633/KX-T7636? (Display Backlight Selection)*1	0 4	0	☐ **Yes—ON in use**
		1	☐ Yes—always ON
		2	☐ No—always OFF
Would you like to dial a preset number simply by going off-hook?	1 1	desired no. (max. 32 digits)	
	1 2	0	☐ **Do not use**
		1	☐ Use
Should you prevent your number being displayed on the called party's telephone? (Calling Line Identification Restriction [CLIR])	1 3	0	☐ **No—Allows your number to be displayed**
		1	☐ Yes—Prevent your number being displayed
Which number should be displayed on the called and calling party's telephone? (Calling/Connected Line Identification Presentation [CLIP/COLP])	1 4	0	**Caller ID assigned to your extension**
		1	Caller ID assigned on the outside line being used

With Compliments Absolute Phone & Data

Item	Programming Input	Selection & Parameter	
Which do you prefer to seize when you go off-hook to make calls? (Preferred Line Assignment—Outgoing)	1 9	0	☐ No line
		1	☐ An idle outside line
		2 + CO button no. (01-36)*2 or (CO)	☐ A CO/ICD Group button
		3 or INTERCOM	☐ **Intercom**
Which line do you prefer to answer when you go off-hook? (Preferred Line Assignment—Incoming)	2 0	0	☐ No line
		1	☐ **The longest ringing line (when multiple calls arrive)**
		2 + CO button no. (01-36)*2 or (CO)	☐ An assigned outside button
How do you prefer to receive an intercom call? (Alternate Receiving—Ring/Voice)*1	2 1	0	☐ **Ringing (Tone Call)**
		1	☐ Directly—The party's voice is heard without ringing.
		2	☐ Ring only—Prohibiting the caller switching to the voice mode.
Should the single line telephone in parallel ring? (Parallelled Telephone)*1*3	2 2	0	☐ No—The telephone will not ring.
		1	☐ **Yes—The telephone will ring.**

With Compliments Absolute Phone & Data

Item	Programming Input	Selection & Parameter	
Do you prefer to answer a call without going off-hook regardless of the AUTO ANS button status? (Forced Answerback Selection)*1	2 3	0	☐ **No—Disable**
		1	☐ Yes—Enable
Which service do you prefer when a calling party is recording a message in your mailbox? (Live Call Screening Mode Set)*1	2 5	0	☐ You can monitor the message through the telephone speaker. **(Hands-free mode)**
		1	☐ Only an alarm tone is heard. (Private mode)
Would you like to keep recording after answering the call in the LCS mode? (LCS Mode Set [After Answering])	2 6	0	☐ **No—Stop recording**
		1	☐ Yes—Keep recording
Do you prefer to receive call waiting for outside calls?	3 0	0	☐ **No (No tone)**
		1	☐ Yes (Tone)
Which type of call waiting for intercom calls do you prefer? (Call Waiting Selection)	3 1	0	☐ **No call**
		1	☐ Tone
		2	☐ Voice announcement through the built-in speaker (OHCA)*4
		3	☐ Voice announcement through the handset (Whisper OHCA)*4
Which type of call waiting tone do you prefer? (Call Waiting Tone Type Selection)	3 2	0	☐ **Tone 1**
		1	☐ Tone 2
Would you like to show a message on the caller's telephone display? (Absent Message)	4 0	0	☐ **No—Off**
		message no. (1-8)	☐ Yes—Shows the selected message.
		9	☐ Yes—Shows your personal message.
Creating your personal message (Personal Absent Message)	4 1	message (max. 16 characters)	

With Compliments Absolute Phone & Data

Item	Programming Input	Selection & Parameter	
Where are your incoming calls forwarded or refused? (Call Forwarding [FWD])/Do Not Disturb [DND])	5 0 / FWD/DND (for both calls) 5 1 (for outside calls) 5 2 (for intercom calls)	0	☐ **Off**
		1	☐ Do Not Disturb (DND)
		2 + desired no. (max. 32 digits)	☐ All—Forward all calls
		3 + desired no. (max. 32 digits)	☐ Busy—Forwarded when your extension is busy.
		4 + desired no. (max. 32 digits)	☐ No Answer—Forwarded when you do not answer.
		5 + desired no. (max. 32 digits)	☐ Busy/No Answer—Forwarded when you do not answer or when your extension is busy.
To set the timer for "No Answer" and "Busy/No Answer" (FWD N/A Timer)	5 3	☐☐ (0-120) seconds (Default: 15 seconds)	
Should you prohibit other people from picking up your calls? (Call Pickup Deny)	6 0	0	☐ **No—Allow**
		1	☐ Yes—Deny
Do you use the headset? (Headset Operation)*1*3	6 1	0	☐ **No—Headset off**
		1	☐ Yes—Headset on
Do you prohibit other people from joining your conversation? (Executive Busy Override Deny)	6 2	0	☐ **No—Allow**
		1	☐ Yes—Deny
Would you like to prohibit paging announcements? (Paging Deny)*1	6 3	0	☐ **No—Allow**
		1	☐ Yes—Deny
Do you prefer to hear the key pad tone? (Key Pad Tone Set)*1	6 4	0	☐ No—Off
		1	☐ **Yes—On**

With Compliments Absolute Phone & Data

Item	Programming Input	Selection & Parameter	
Do you want background music through your telephone speaker while on-hook? (Background Music [BGM])*1	6 5	0	☐ **No—Off**
		KX-TDA100/KX-TDA200: 1 + BGM no. (1 digit) KX-TDA30: 1 1	☐ Yes—On
Would you like to set your extension PIN or change a stored extension PIN to new one? (Extension PIN [Personal Identification Number])	9 0	extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN	To set an extension PIN
		stored extension PIN + new extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN	To change a stored extension PIN to new one
To prevent other people from using your telephone (Extension Dial Lock)	9 1	**extension PIN (max. 10 digits) + 0**	☐ **To unlock**
		extension PIN (max. 10 digits) + 1	☐ To lock
To prevent other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box (Display Lock)*1	9 2	**extension PIN (max. 10 digits) + 0**	☐ **To unlock**
		extension PIN (max. 10 digits) + 1	☐ To lock
Do you prefer to set the One-touch dialling only? (One-touch Dialling Assignment Mode Selection)	# *	0	☐ **No—Normal (Any Flexible CO buttons can be modified.)**
		1	☐ Yes—Only One-touch dialling buttons can be modified. However, to modify them, there is no need to enter "2" before the number.

*1: Not available for a PS

With Compliments Absolute Phone & Data

*2: CO button numbers (25-36) are available only when the Add-on Key Module is set up to your telephone.

*3: Not available for the KX-T7665

*4: Only available for certain digital proprietary telephones. Consult your dealer.

- **WARNING**
  There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).
  The cost of such calls will be billed to the owner/renter of the PBX.
  To protect the PBX from this kind of fraudulent use, we strongly recommend:
  a) Keeping your PIN secret.
  b) Selecting a complex, random PIN that cannot be easily guessed.
  c) Changing your PIN regularly.
- After the programme number is entered, the programme title is displayed.
  The programming screen can be changed with the Navigator Key (Up or Down).

- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.

To store the names and numbers in personal speed dialling



- * To enter characters, refer to "Entering Characters".
- The number of personal speed dialling numbers available per extension (default: 10 numbers stored in locations "00" to "09") can be increased to a maximum of 100. For more details, consult your dealer.

With Compliments
Absolute Phone & Data

To edit the names and numbers of personal speed dialling



With Compliments
Absolute Phone & Data

Clearing Features

You can clear or change to features as follows:

Features	Default Setting
Display Switching Mode	**Automatic**
Hot Line	**Off**
Calling Line Identification Restriction [CLIR]	**Allow**
Calling/Connected Line Identification Presentation [CLIP/COLP]	**Caller ID assigned on your extension**
Preferred Line Assignment—Outgoing	**Intercom**
Preferred Line Assignment—Incoming	**The longest ringing line**
Alternate Receiving—Ring/Voice	**Ringing (Tone Call)**
Parallelled Telephone	**Paired SLT will ring**
Forced Answerback Selection	**Disable**
Live Call Screening Mode Set	**Hands-free mode**
LCS Mode Set [After Answering]	**Stop recording**
Call Waiting Selection—Intercom/Outside Calls	**Disable (No call/No tone)**
Call Waiting Tone Type Selection	**Tone 1**
Absent Message	**Off**
Personal Absent Message	**Cleared**
Call Forwarding [FWD]/Do Not Disturb [DND]—Intercom/Outside Calls	**Off**
FWD N/A Timer	**15 seconds**
Call Pickup Deny	**Allow**
Headset Operation	**Headset off**
Executive Busy Override Deny	**Allow**
Paging Deny	**Allow**
Key Pad Tone Set	**On**
Background Music [BGM]	**Off**
Data Line Security	**Off**
Connected Line Identification Restriction [COLR]	**Allow**
Log-in/Log-out	**Log-in**
Message Waiting	**Off**
Timed Reminder	**Cleared**

With Compliments
Absolute Phone & Data

To set



- If you do not desire that the Call Waiting, FWD/DND or Hot Line to be cleared by this feature, please ask your dealer.

With Compliments
Absolute Phone & Data

3.1.3 Customising the Buttons

You can change the flexible CO buttons/DSS buttons, and programmable feature (PF) buttons on PTs, DSS Consoles, Add-on Key Modules, and PSs to the following feature buttons. For example, if your telephone has more CO buttons than available outside lines, you may change unused CO buttons to one-touch buttons.

- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.



Buttons	Programmable Button			Programming Input
	CO	DSS	PF	
Loop-CO (L-CO)	✔	✔		[*]
Group-CO (G-CO)	✔	✔		[#] + Outside line group no. (2 digits)
Single-CO (S-CO)	✔	✔		[0] + Outside line no. (3 digits)
Direct Station Selection (DSS)	✔	✔		[1] + Extension no.
One-touch Dialling*1	✔	✔	✔	[2]*2 + Desired no. (max. 32 digits)
Incoming Call Distribution Group (ICD Group)	✔	✔		[3] [0] + Incoming call distribution group extension no.
Message	✔	✔		[4] [0]
Message for Another Extension	✔	✔		[4] [0] + Extension no./Incoming call distribution group extension no.
Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls	✔	✔		[4] [1]
FWD/DND—Outside calls	✔	✔		[4] [2]
FWD/DND—Intercom calls	✔	✔		[4] [3]

With Compliments
Absolute Phone & Data

Buttons	Programmable Button			Programming Input
	CO	DSS	PF	
Group FWD—Both calls	✔	✔		4 4 + Incoming call distribution group extension no.
Group FWD—Outside calls	✔	✔		4 5 + Incoming call distribution group extension no.
Group FWD—Intercom calls	✔	✔		4 6 + Incoming call distribution group extension no.
Account	✔	✔		4 8
Conference	✔	✔		4 9
Terminate	✔	✔		5 0
External Feature Access (EFA)	✔	✔		5 1
Charge Reference	✔	✔		5 2
Call Park	✔	✔		5 3 + Parking zone no. (2 digits)
Call Park (Automatic Park Zone)	✔	✔		5 3 *
Call Log*3	✔	✔		5 4
Call Log for ICD Group*3	✔	✔		5 4 + Incoming call distribution group extension no.
Log-in/Log-out	✔	✔		5 5
Log-in/Log-out of a specified group	✔	✔		5 5 + Incoming call distribution group extension no.
Log-in/Log-out for all groups	✔	✔		5 5 *
Hurry-up	✔	✔		5 6 + Incoming call distribution group extension no.
Wrap-up	✔	✔		5 7
System Alarm*3	✔	✔		5 8
Time Service (Day/Night/ Lunch/Break)	✔	✔		5 9 + 0/1/2/3*4 (+ # + Tenant no.)
Answer*3	✔	✔		6 0

With Compliments Absolute Phone & Data

Buttons	Programmable Button			Programming Input
	CO	DSS	PF	
Release*3	✔	✔		6 1
Toll Restriction/Call Barring	✔	✔		6 2 + Toll Restriction/Call Barring Level (1-7)
ISDN Service*5	✔	✔		6 3 + Desired no. (max. 32 digits)
Calling Line Identification Restriction (CLIR)	✔	✔		6 4
Connected Line Identification Restriction (COLR)	✔	✔		6 5
ISDN-Hold	✔	✔		6 6
Headset*3*6	✔	✔		6 7
Time Service Switching Mode (Automatic/Manual)	✔	✔		6 8 (+ Tenant no.)
Network Direct Station Selection (NDSS)*8	✔	✔		6 9 + Another PBX extension no.
CTI	✔			7 0
Check-in*3	✔	✔		8 0
Check-out*3	✔	✔		8 1
Two-way Record*7	✔	✔		9 0 + Voice mail floating extension no.*9
Two-way Transfer*7	✔	✔		9 1 + Voice mail floating extension no.*9
One-touch Two-way Transfer*7	✔	✔		9 1 + Voice mail floating extension no.*9 + # + Extension no./Incoming call distribution group extension no.
Live Call Screening (LCS)*7	✔	✔		9 2
Voice Mail Transfer*7	✔	✔		9 4 + Voice mail floating extension no.*9

With Compliments Absolute Phone & Data

- *1 "✳", "#", FLASH/RECALL, PAUSE, SECRET (INTERCOM) and T (Transfer) can also be stored.
  If you do not want to display the stored number when making a call, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.
  If you store an outside party's number, you should first store a line access number.
  If you need to enter an account code, you can enter the specified account code before the line access number.
  <Example>



- *2 For a PF button, "2" is not required to enter before the desired number.
- *3 This button is not available for a PS.
- *4 0: Day/Night/Lunch/Break, 1: Day/Night/Break, 2: Day/Night/Lunch, 3: Day/Night
- *5 Availability of this button depends on the ISDN service of your telephone company. Refer to "1.2.5 Accessing the ISDN Service (ISDN Service Access)".
- *6 This button is not available for the KX-T7665.
- *7 This button is used for the integrated voice mail features.
- *8 The button may not be available depending on the networking method in use or the settings of the PBX. For more details, consult your dealer.
- *9 The default voice mail floating extension number is 500.
- **To exit at any time,** lift the handset.

- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.

With Compliments
Absolute Phone & Data

To distinguish the ringing tones for each CO, INTERCOM or ICD Group button (Digital proprietary telephone only)



- * Available tone types vary depending on the telephone you are using:
  - KX-T7600 series (except KX-T7665): Tone types "01" to "30" are available.
  - KX-T7665: Only tone types "01" to "08" are available.
    It is possible to enter a tone type number from "09" to "30", but you will hear tone type "01".
  - Other telephones: Only tone types "01" to "08" are available.
    It is possible to enter a tone type number from "09" to "30", but you will hear tone type "02".

To clear the button



With Compliments
Absolute Phone & Data

3.2 Manager Programming

3.2.1 Programming Information

The manager can programme the following items.

- Call Charges
- Other Extensions Control

Available Extension

The extension assigned as a manager

Required Telephone

A Panasonic Proprietary Telephone with display (over 2 lines)
(e.g., KX-T7636)

Manager Password

To enter programming mode, the manager password (max. 10 digits) is required. (Default: 1234)

Conditions

The programming extension must be idle, on-hook and holding no calls.

With Compliments
Absolute Phone & Data

3.2.2 Manager Programming

Changing Call Charges and Extension Control



Item	Programming Input
Changing the manager password.	0 0 + ENTER + Password (max. 10 digits) + ENTER
Viewing extension call charges.	0 1 + ENTER + Extension no.
Clearing extension call charges.	0 1 + ENTER + Extension no. + ENTER + CLEAR
Setting the budget for extension call charges.	0 2 + ENTER + Extension no. + Charge* + ENTER
Viewing call charges for each verified code.	0 3 + ENTER + Verified code
Clearing call charges for each verified code.	0 3 + ENTER + Verified code + CLEAR + ENTER
Setting the budget for each verified code.	0 4 + ENTER + Verified code + Charge* + ENTER
Viewing call charges for each outside line.	0 5 + ENTER + Outside line no. (3 digits)
Assigning a charge rate for each outside line group.	0 6 + ENTER + Outside line group no. (2 digits) + Charge rate* + ENTER
Clearing all charges.	0 7 + ENTER + ENTER
Printing the total call charge.	0 8 + ENTER + ENTER
Locking/unlocking other extensions. (Remote Extension Dial Lock)	9 0 + ENTER + Extension no. + 1 (to lock)/ 0 (to unlock) + ENTER
Clearing the PIN and PIN lock for extensions.	9 1 + ENTER + Extension no. + ENTER

With Compliments Absolute Phone & Data

Item	Programming Input
Clearing the PIN and PIN lock for verified codes.	9 2 + ENTER + Verified code + ENTER
Setting the verified code PIN.	9 3 + ENTER + Verified code + PIN (max. 10 digits) + ENTER

- **WARNING**
  There is a risk that fraudulent telephone calls will be made if a third party discovers your password (verified code PIN).
  The cost of such calls will be billed to the owner/renter of the PBX.
  To protect the PBX from this kind of fraudulent use, we strongly recommend:
  a) Keeping your PIN secret.
  b) Selecting a complex, random PIN that cannot be easily guessed.
  c) Changing your PIN regularly.
- * To enter a decimal point, press ✳ .

With Compliments
Absolute Phone & Data

3.3 Customising Your System (System Programming)

3.3.1 Programming Information

You can customise your system according to your requirements.
[Your system already has default settings (factory installed).]

The programming is shown below. (Programme number)

- The date and time [000]
- System speed dialling numbers and names [001]/[002]
- Extension number and name [003]/[004]

Available Extension

The extension allowed through COS programming

Required Telephone

A Panasonic Proprietary Telephone with display (over 2 lines)
(e.g., KX-T7636)

System Password

To enter programming mode, the system password (max. 10 digits) is required. (Default: 1234)

Conditions

The programming extension must be idle, on-hook and holding no calls.

List

Before programming, decide the settings and write them down. Your notes will provide a useful record of the programming for future reference. Your dealer also has programming records which contain all of the system programming. You may ask for photo copies of these tables to be aware of the facilities and features available.

With Compliments
Absolute Phone & Data

Icon Descriptions

Fixed Buttons		Function
T7600/NT136	T7200/T7400/T7500	
		PREVIOUS (PREV)
		NEXT
		STORE (ENTER)
	None	Back to Previous Menu (CANCEL)
		SHIFT
		PROGRAM
		END
		SELECT
		FLASH
		CLEAR
		SECRET

With Compliments Absolute Phone & Data

Procedure

The basic steps are shown below.

1. ***Entering the programming mode***



2. ***Programming***

You can enter each programme number (3 digits).

- **To exit the programming mode at any time,** lift the handset.

3. ***Exiting the mode***



- **To exit the programming mode at any time,** lift the handset.

With Compliments
Absolute Phone & Data

3.3.2 System Programming

Date & Time [000]

The proprietary telephones display the current date and time while on-hook.

[In 12-hour Format]



[In 24-hour Format]



With Compliments Absolute Phone & Data

- **After changing the desired values,** you can press the ENTER button. You do not have to perform the rest of the steps.
- The clock starts immediately after the ENTER button is pressed.
- You cannot leave a value empty.
- You can clear the entry by pressing the CLEAR button.
- **To confirm your entry after storing data:**
  - The STORE button light: Lights red
  - Confirmation Tone:
    One beep: Your entry is accepted.
    Three beeps: Your entry is rejected.

System Speed Dialling Number [001]

You can store the phone numbers of frequently dialled destinations.



With Compliments Absolute Phone & Data

- If the desired number is more than 32 digits, divide the number and store it into more than one speed dialling number.
- "✳", "#", FLASH/RECALL, PAUSE, and SECRET (INTERCOM) can also be stored.

  If you do not want to display the stored number when making a call, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.

  If you store an outside party's number, you should first store a line access number.

  If you need to enter an account code, you can enter the specified account code before the line access number.

  <Example>



System Speed Dialling Name [002]

You can store the name associated with the speed dialling number. These names are displayed when making calls using the display operation. To enter characters, refer to "Entering Characters".



Extension Number [003]

You can assign an extension number to each extension.



With Compliments
Absolute Phone & Data

- The leading number(s) should be the same as the number(s) assigned for Flexible Numbering. Consult your dealer.
- A duplicate entry is invalid.

Extension Name [004]

You can store the name of an extension user. This is useful if you want to know who is calling, or who you are calling when making an intercom call using the directory.
To enter characters, refer to "Entering Characters".



With Compliments
Absolute Phone & Data

Section 4

Appendix

This chapter provides the Troubleshooting, the Feature Number Table and Tone List. Check the Troubleshooting section before consulting your dealer.

With Compliments
Absolute Phone & Data

4.1 Troubleshooting

4.1.1 Troubleshooting

Troubleshooting

Problem	Remedy
The telephone does not work properly.	• ➡ Consult your dealer.
I cannot use the telephone.	• **The telephone is locked.** ➡ Unlock your telephone. (☞ 1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control) • **Your telephone is connected to an eXtra Device Port.** ➡ System programming is required. Consult your dealer.
Some features do not work.	• **System management may restrict certain features.** ➡ Consult your manager. • **The feature numbers have changed.** ➡ Confirm the revised number and try again.
Even though following the manual instructions, none of the operations work when using a proprietary telephone.	• **The Intercom line was not seized.** The seized line, when going off-hook, was changed by personal setting. (☞ 3.1.2 Settings on the Programming Mode) ➡ In the manual, going off-hook means an Intercom line is seized. If the setting has been changed, press the INTERCOM button after going off-hook and follow the instructions.
The parallelled single line telephones do not ring.	• **"No ring" may be selected.** Change the setting to ring. (☞ 1.7.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone))
The telephone does not work using the personal settings or with other settings. (One-touch dialling, forwarding destination, etc.)	• **The extension line has been changed.** The previous telephone's settings have not been cleared. ➡ Clear the settings and then programme your desired settings again. (☞ 1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear), 3.1.1 Customising Your Phone (Personal Programming), 3.1.3 Customising the Buttons)
My proprietary telephone does not have a feature button.	• **Some models do not have the feature button.** ➡ Change a flexible button to the desired button. (☞ 3.1.3 Customising the Buttons) ➡ Enter the specified feature number instead of the feature button. (☞ 1.1.1 Before Operating the Telephones)

With Compliments
Absolute Phone & Data

Problem	Remedy
A reorder tone is audible or "Restricted" is displayed.	• **The telephone is locked.** ➡ Unlock your telephone. (☞ 1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control) • **Toll restriction is activated.** ➡ Consult your manager or dealer. • **An account code is required.** (☞ 1.2.7 Calling without Restrictions, Using an Account Code (Account Code Entry) in 1.2.1 Basic Calling)
I cannot make an outside call using the One-touch Dialling button or speed dialling.	• **A line access number was not stored.** ➡ A line access number is required for outside calls. (☞ 1.2.1 Basic Calling, 3.1.3 Customising the Buttons)
I cannot remember the feature numbers.	• ➡ Ask your dealer to change the feature numbers for easier use.
While talking to an outside party, the line is disconnected.	• **The time limit has run out.** (☞ 1.4.1 Transferring a Call (Call Transfer), 1.4.5 Multiple Party Conversation) ➡ Consult your dealer to extend the time, if necessary.
Redialling does not function.	• **The stored number was more than 32 digits or an extension number.** (☞ 1.2.3 Redial)
The personal computer and fax machine communication failed.	• **An indication tone may have interrupted communication.** (☞ 1.7.9 Protecting Your Line against Notification Tones (Data Line Security))
I do not want to show my telephone number to the calling or called party's telephone.	• ➡ Consult your manager or dealer.
I want to show my telephone number to the calling or called party's telephone.	• (☞ 1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]))
I cannot send a call waiting tone to the dialled extension.	• **The other party has not set the Call Waiting feature.** (☞ Sending a Call Waiting Notification (Call Waiting), 1.4.4 Answering Call Waiting, 1.7.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/ Whisper OHCA)) • **The other party has set Data Line Security.** (☞ 1.7.9 Protecting Your Line against Notification Tones (Data Line Security))
I forgot the password.	• Ask the manager to assist you. (☞ 2.1.1 Extension Control)
The background music started suddenly.	• ➡ Turn off the music. (☞ 1.7.8 Turning on the Background Music (BGM), 2.1.4 Turning on the External Background Music (BGM))

With Compliments Absolute Phone & Data

Problem	Remedy
I do not want to display a number which is stored in memory.	• ➡ Conceal the number. (☞ Storing Names and Numbers, 3.1.3 Customising the Buttons)
I want to confirm my extension number.	• (☞ Your Extension Number in 1.1.1 Before Operating the Telephones)
The date and time are not correct.	• **Set the date and time by system programming.** (☞ Date & Time [000] in 3.3.2 System Programming)
The display is not shown well.	• ➡ Change the Display contrast level. (☞ 3.1.2 Settings on the Programming Mode)
I want to distinguish the tones.	• (☞ To distinguish the ringing tones for each CO, INTERCOM or ICD Group button (Digital proprietary telephone only), 3.1.3 Customising the Buttons)
The MESSAGE button light lit.	• **Another extension left you a message waiting indication while you were on the phone or away from your desk.**

With Compliments
Absolute Phone & Data

4.2 Feature Number Table

4.2.1 Feature Number Table

Numbers listed below are the default settings. There are flexible feature numbers and fixed feature numbers. If you change the flexible feature numbers, fill in your assigned numbers (new) in the list for future reference.

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.2.1 Basic Calling		
To call an operator (Operator Call)	9/0 ( )	
To select an idle outside line automatically (Automatic Line Access)	0/9 ( )	outside phone no.
To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)	8 ( )	outside line group no. (2 digits) + outside phone no.
Making a Call to a Private Network (TIE Line Access)	7 ( )	private phone no.
Using an Account Code (Account Code Entry)	✳49 ( )	account code + # + outside phone no.
1.2.2 Easy Dialling		
Using Numbers Stored at Your Extension (Personal Speed Dialling)		
– To store	✳30 ( )	personal speed dialling no. (2 digits) + phone no. + #
– To dial	✳✳ ( )	✳ + personal speed dialling no. (2 digits)
Using Numbers Stored in the PBX (System Speed Dialling)		
– To dial	✳✳ ( )	system speed dialling no. (3 digits)
To a Preset Number by Going Off-hook (Hot Line)	✳740 ( )	
– To store		2 + phone no. + #
– To set		1
– To cancel		0
1.2.3 Redial		
Redialling the Last Number You Dialled (Last Number Redial)	# ( )	

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.2.4 When the Dialled Line is Busy or There is No Answer		
To cancel callback ringing (Automatic Callback Busy Cancel)/To cancel (CCBS Cancel)	✳46 ( )	
Leaving a Message Waiting Indication/ Calling Back the Caller Who Left an Indication (Message Waiting)	✳70 ( )	
For a caller		
– To leave/cancel		1/0 + extension no.
For a called extension		
– To call back		2
– To clear		0 + your extension no.
1.2.7 Calling without Restrictions		
Using Your Calling Privileges at Another Extension (Remote COS Access)	✳47 ( )	extension no. + extension PIN + phone no.
To call with a verified code (Verified Code Entry)		✳ + verified code + verified code PIN + phone no.
1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])		
Calling through DISA		
– To an extension (In All Security Mode only)		your extension no./(✳ + verified code) + extension PIN/verified code PIN + extension no.
– To an outside party (In Trunk Security Mode/All Security Mode only)		your extension no./(✳ + verified code) + extension PIN/verified code PIN + outside phone no.
1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)		your extension no. + extension PIN + feature no.
– From another extension		
– Through DISA		

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)		
Answering a Call from Another Telephone (Call Pickup)		
– Group	✳40 ( )	group no. (2 digits)
– Directed	✳41 ( )	extension no.
Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)	✳720 ( )	
– To deny		1
– To allow		0
1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])		
– Calls through an external speaker	✳42 ( )	KX-TDA100/KX-TDA200: speaker no. (1 digit) KX-TDA30: 1
1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])	✳7✳3 ( )	
1.4.1 Transferring a Call (Call Transfer)		
Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)	✳62 ( )	phone no.
1.4.2 Holding a Call		
To hold (Call Hold)/To retrieve a call (Call Hold Retrieve)	✳50 ( )	
To retrieve a call (Call Hold Retrieve)		
– Specified with a held line number	✳53 ( )	outside line no. which is held (3 digits)
– Specified with a holding extension number	✳51 ( )	extension no. which has a held call
Holding in a System Parking Zone (Call Park)	✳52 ( )	
– To set		parking zone no. (2 digits)/✳
– To retrieve		stored parking zone no. (2 digits)

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.4.4 Answering Call Waiting		
Answering Call Waiting in the PBX	✳50 ( )	
Answering Call Waiting from the Telephone Company	✳60 ( )	
1.4.5 Multiple Party Conversation		
Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)	✳62 ( )	phone no. + TRANSFER button + 3
1.5.1 Forwarding Calls		
Forwarding Your Calls (Call Forwarding [FWD])/ 1.7.2 Refusing Incoming Calls (Do Not Disturb [DND])		
– Both Calls	✳710 ( )	0 (Cancel)/
– Outside Calls	✳711 ( )	1 (Do Not Disturb [DND])/
– Intercom Calls	✳712 ( )	2 (All calls) + phone no. + #/ 3 (Busy) + phone no. + #/ 4 (No Answer) + phone no. + #/ 5 (Busy/No Answer) + phone no. + #/ 7 (Follow Me) + your extension no./ 8 (Follow Me Cancel) + your extension no.
– To set the timer for "No Answer" and "Busy/No Answer"	✳713 ( )	00-99 (second)
To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)		
– Both Calls	✳714 ( )	1 (Set) + ICD Group extension no. + phone no. + #/0 (Cancel) + ICD Group extension no.
– Outside Calls	✳715 ( )	
– Intercom Calls	✳716 ( )	

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)	✳7✳5 ( )	
– To set		outside line no. + # + multiple subscriber no. + # + 2 (Unconditional)/3 (Busy)/4 (No Reply) + phone no. + #
– To cancel		outside line no. + # + multiple subscriber no. + # + 0
– To confirm		outside line no. + # + multiple subscriber no. + # + 1
1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only)		
Recording a Normal Greeting Message		
– To record	✳38 ( )	1
– To play back		2
– To clear		0
Recording a Greeting Message for Each Time Mode		
– To record		8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 1
– To play back		8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 2
– To clear		8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 0
To leave a voice message directly to another extension's message box		# + 6 + extension no.
Listening to Voice Messages Left by Callers		3
Redirecting Your Calls to Your Message Box		
– Both Calls	✳710 ( )	0 (Cancel)/
– Outside Calls	✳711 ( )	2 (All Calls) + floating extension no. for SVM card*5 + #/
– Intercom Calls	✳712 ( )	3 (Busy) + floating extension no. for SVM card*5 + #/
		4 (No Answer) + floating extension no. for SVM card*5 + #/
		5 (Busy/No Answer) + floating extension no. for SVM card*5 + #

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.5.3 Showing a Message on the Caller's Telephone Display (Absent Message)	✳750 ( )	
– To set		1-9 (+ parameter) + #
– To cancel		0
1.5.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)	✳77 ( )	
– To lock		1
– To unlock		0 + extension PIN
1.6.1 Paging		
Group Paging	✳33 ( )	paging group no. (2 digits)
1.6.2 Answering/Denying a Paging Announcement		
– To answer	✳43 ( )	
– To deny	✳721 ( )	1
– To allow		0
1.6.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)		
– To call and make an announcement	✳32 ( )	broadcasting group no. (1 digit)
1.7.1 Setting the Alarm (Timed Reminder)	✳760 ( )	
– To set		12H: 1 + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily) 24H: 1 + hour/minute + 0 (once)/1 (daily)
– To cancel		0
1.7.3 Receiving Call Waiting (Call Waiting/ Off-hook Call Announcement [OHCA]/ Whisper OHCA)		
– For intercom calls (No call/Tone/OHCA/Whisper OHCA)	✳731 ( )	0 (No call)/1 (Tone)/2 (OHCA)/3 (Whisper OHCA)
– For outside calls (No tone/Tone)	✳732 ( )	0 (No tone)/1 (Tone)

With Compliments
Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.7.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])	✳7✳2 ( )	
– Public		1
– Your extension		2
1.7.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])	✳7✳0 ( )	
– To show		0
– To prevent		1
1.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])	✳7✳1 ( )	
– To show		0
– To prevent		1
1.7.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)	✳733 ( )	
– To prevent		1
– To allow		0
1.7.8 Turning on the Background Music (BGM)	✳751 ( )	
– To set		KX-TDA100/KX-TDA200: BGM no. (1 digit) KX-TDA30: 1
– To cancel		0
1.7.9 Protecting Your Line against Notification Tones (Data Line Security)	✳730 ( )	
– To set		1
– To cancel		0
1.7.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone)	✳39 ( )	
– Ring		1
– No Ring		0

With Compliments
Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.7.12 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) – To set – To cancel	✳48 ( )	 1 + paired wired extension no. 0
1.7.13 Clearing Features Set at Your Extension (Extension Feature Clear)	✳790 ( )	
1.8.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) Log-in Log-out To enter/leave the Not Ready mode	 ✳736 ( ) ✳735 ( )	 1 + ICD Group extension no./✳ 0 + ICD Group extension no./✳ 1 (Not Ready)/0 (Ready)
*3 1.8.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)	✳739 ( )	ICD Group extension no.
1.9.1 If a Doorphone/Door Opener is Connected Doorphone Call Opening a Door (Door Open)	 ✳31 ( ) ✳55 ( )	 doorphone no. (2 digits) doorphone no. (2 digits)
1.9.2 If an External Relay is Connected	✳56 ( )	relay no. (2 digits)
1.9.4 If a Host PBX is Connected Accessing External Services (External Feature Access [EFA])	✳60 ( )	service code
1.9.5 If a Voice Processing System is Connected Call Forwarding to Voice Mail (Voice Mail Integration) – Both Calls	✳710 ( )	0 (Cancel)/

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
– Outside Calls	✳711 ( )	2 (All Calls)/
– Intercom Calls	✳712 ( )	3 (Busy)/ 4 (No Answer)/ 5 (Busy/No Answer) + voice mail floating extension no.*6 + #
1.10.1 Using the Same Settings as Your Previous Extension (Walking Extension)	✳727 ( )	your previous extension no. + extension PIN
2.1.1 Extension Control *1 To lock/unlock other extensions (Remote Extension Dial Lock)		
– To unlock	✳782 ( )	extension no.
– To lock	✳783 ( )	extension no.
*2 2.1.2 Time Service Mode Control – Day/Night/Lunch/Break	✳780 ( )	0/1/2/3
*1 2.1.4 Turning on the External Background Music (BGM)	✳35 ( )	
– To play		KX-TDA100/KX-TDA200: external pager no. (1 digit)/✳ + BGM no. (1 digit) KX-TDA30: 11
– To stop		KX-TDA100/KX-TDA200: external pager no. (1 digit)/✳ + 0 KX-TDA30: 10
*1 2.1.5 Recording Outgoing Messages (OGM)	✳36 ( )	
– To record		1 + OGM floating extension no.*7
– To play back		2 + OGM floating extension no.*7
– To record from an external BGM (MOH) port		KX-TDA100/KX-TDA200: 3 + BGM port no. (1 digit) + OGM floating extension no.*7 KX-TDA30: 31 + OGM floating extension no.*7
– To clear		0 + OGM floating extension no.*7
*1 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)	✳785 ( )	outside line no. (3 digits)

With Compliments Absolute Phone & Data

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features)		
*4 Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)	✳76✳ ( )	
– To set		12H: 1 + extension no. + hour/minute + 0 (AM)/ 1 (PM) + 0 (once)/1 (daily) 24H: 1 + extension no. + hour/minute + 0 (once)/1 (daily)
– To cancel		0 + extension no.
– To confirm		2 + extension no.
Recording room information using a room extension	✳761 ( )	message no. (+ parameter) + #
*1 2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor	✳784 ( )	another PBX extension no. + #
3.1.1 Customising Your Phone (Personal Programming)		
Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])	✳799 ( )	
– To set		1 + extension PIN + # + same extension PIN + #
– To cancel		0 + stored extension PIN

*1: Manager only

*2: Manager and preprogrammed extension user only

*3: Supervisor only

*4: Hotel operator only

*5: The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

*6: The default voice mail floating extension number is 500.

*7: The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

With Compliments
Absolute Phone & Data

Feature (While busy, DND or call tone is heard)	Default
1.2.4 When the Dialled Line is Busy or There is No Answer	
Sending a Call Waiting Notification (Call Waiting)	1
To an Extension Refusing the Call (DND Override)	
Joining an Existing Call (Executive Busy Override)	3
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)	4
Monitoring Another Extension (Call Monitor)	5
Reserving a Busy Line (Automatic Callback Busy)/Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])	6
1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)	✳

Feature (While dialling or talking)	Fixed Number
1.4.5 Multiple Party Conversation	
Adding Other Parties during a Conversation (Conference)	3
1.9.1 If a Doorphone/Door Opener is Connected	
From any extension while talking to the doorphone	5

With Compliments
Absolute Phone & Data

4.3 What is This Tone?

4.3.1 What is This Tone?

While on-hook

Ring Tones

The following tones are programmable allowing recognition of call type (Outside, Intercom or Doorphone).

Tone 1

Tone 2

Tone 3

Tone 4



When going off-hook

Dial Tones

Tone 1

Normal



With Compliments
Absolute Phone & Data

Tone 2



- When there are messages that have previously been listened to and no new messages in your message box
- When any of the following features are set:
  - Absent Message
  - Background Music
  - Call Forwarding
  - Call Pickup Deny
  - Call Waiting
  - Do Not Disturb
  - Extension Dial Lock
  - Executive Busy Override Deny
  - Hot Line
  - Timed Reminder

Tone 3

- After pressing TRANSFER or Recall/ hookswitch to hold a call temporarily (e.g., Call Splitting)
- When the recording space of the Built-in Simplified Voice Message feature becomes almost full
- While a called PS is being searched
- When Account Code Entry is performed
- When answering a Timed Reminder call with no message
- When answering an external sensor call

Tone 4

Message waiting indication was received.



With Compliments
Absolute Phone & Data

When you make calls

Busy Tone



Reorder Tone

The outside line you tried to seize is not assigned or denied.

Ringback Tone 1

Ringback Tone 2

Do Not Disturb (DND) Tone

The dialled extension is refusing incoming calls.

While off-hook

Indication Tones

Tone 1

Call waiting tone



Tone 2

A call is on hold longer than the specified time



When talking to an outside party

Warning Tone

This tone is sent 15, 10 and 5 seconds before the specified time for disconnection.

When setting the features or programming

Confirmation Tones

Tone 1

The feature setting was set successfully.

With Compliments
Absolute Phone & Data

Tone 2

Before receiving a page through an external speaker

Tone 3

Before the following features activate:

- Retrieving a held call
- Picking up another call
- Paging/Answering a paging announcement
- Answering the call through a speaker

Tone 4

Establishing or leaving a conference



Tone 5

A call has been put on hold.



With Compliments
Absolute Phone & Data

4.4 Revision History

4.4.1 KX-TDA100/KX-TDA200 MPR Version 1.1

New Contents

- 1.4.5 Multiple Party Conversation

  Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)
- 1.6.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)

Changed Contents

- 1.1.1 Before Operating the Telephones

  When You Use a Panasonic Proprietary Telephone
  – FLASH/RECALL
- 1.2.4 When the Dialled Line is Busy or There is No Answer

  Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)
  – To clear message waiting indications left on your extension
- 1.11.1 Using the Call Log

  Calling with the Incoming Call Log
  Calling with the Outgoing Call Log
- 1.11.2 Using the Directories

  Calling with the Directory
  Storing Names and Numbers
  Entering Characters

With Compliments
Absolute Phone & Data

4.4.2 KX-TDA100/KX-TDA200 MPR Version 2.0

New Contents

- 1.1.1 Before Operating the Telephones
  When You Use a Panasonic Proprietary Telephone
  – Network Direct Station Selection (NDSS)
  – CTI
  – Check-in
  – Check-out
- 1.2.1 Basic Calling
  Making a Call to a Private Network (TIE Line Access)
  – To call with one touch
- 1.9.2 If an External Relay is Connected
- 1.9.3 If an External Sensor is Connected
- 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)
- 2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features)
- 2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor

Changed Contents

- 1.2.2 Easy Dialling
  Using Numbers Stored at Your Extension (Personal Speed Dialling)
  – To store a phone number

With Compliments
Absolute Phone & Data

4.4.3 KX-TDA30 MPR Version 1.1

New Contents

- 1.4.5 Multiple Party Conversation
  Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)
- 1.6.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)

Changed Contents

- 1.11.1 Using the Call Log
  Calling with the Incoming Call Log
  Calling with the Outgoing Call Log
- 1.11.2 Using the Directories
  Calling with the Directory
  Storing Names and Numbers
  Entering Characters

With Compliments
Absolute Phone & Data

4.4.4 KX-TDA30 MPR Version 2.0

New Contents

- 1.1.1 Before Operating the Telephones
  When You Use a Panasonic Proprietary Telephone
  – Network Direct Station Selection (NDSS)
  – CTI
  – Check-in
  – Check-out
- 1.2.1 Basic Calling
  Making a Call to a Private Network (TIE Line Access)
  – To call with one touch
- 1.9.2 If an External Relay is Connected
- 1.9.3 If an External Sensor is Connected
- 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)
- 2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features)
- 2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor

Changed Contents

- 1.2.2 Easy Dialling
  Using Numbers Stored at Your Extension (Personal Speed Dialling)
  – To store a phone number

With Compliments
Absolute Phone & Data

4.4.5 KX-TDA30 MPR Version 2.2

New Contents

- 1.1.1 Before Operating the Telephones
  When You Use a Panasonic Proprietary Telephone
  – Network Direct Station Selection (NDSS)
  – CTI
  – Check-in
  – Check-out
- 1.2.1 Basic Calling
  Making a Call to a Private Network (TIE Line Access)
  – To call with one touch
- 1.5.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only)
- 1.9.2 If an External Relay is Connected
- 1.9.3 If an External Sensor is Connected
- 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)
- 2.1.7 Using the Telephones in a Hotel-type Environment (Hospitality Features)
- 2.1.8 Releasing Network Direct Station Selection (NDSS) Monitor

Changed Contents

- 1.2.2 Easy Dialling
  Using Numbers Stored at Your Extension (Personal Speed Dialling)
  – To store a phone number
- 4.3.1 What is This Tone?

With Compliments
Absolute Phone & Data

Index

With Compliments
Absolute Phone & Data

A

Absent Message 101, 181, 212
Accessing External Services (External Feature Access [EFA]) 137
Accessing System Features (System Feature Access) 156
Accessing the ISDN Service (ISDN Service Access) 44
Accessing the Message Box of Another Extension from Your Extension 100
Accessing Your Message Box from an Outside Telephone 99
Account 21, 189
Account Code Entry 29, 207
Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN) 79
Adding Other Parties during a Conversation (Conference) 72
After Moving to a New Location in the Office 144
Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out) 166
Alternate Calling—Ring/Voice 45, 217
Alternate Receiving—Ring/Voice 180
Alternating the Calling Method (Alternate Calling—Ring/Voice) 45
Answer 19, 22, 55, 189
Answering a Call from Another Telephone (Call Pickup) 53
Answering a Call Ringing at Another Telephone (Call Pickup) 53
Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) 54
Answering Call Waiting 68
Answering Call Waiting from the Telephone Company 71
Answering Call Waiting in the PBX 68
Answering Calls 51
Answering Hands-free (Hands-free Answerback) 52
Answering/Denying a Paging Announcement 107
Appendix 203
Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number]) 176
AUTO ANS (Auto Answer)/MUTE 18
AUTO DIAL/STORE 17
Automatic Call Hold 64
Automatic Callback Busy 35, 217
Automatic Callback Busy Cancel 36, 208
Automatic Line Access 26, 207
Automatic Redial 34

B

Background Music (BGM) 120, 183, 213
Basic Calling 25
Before Leaving Your Desk 85
Before Operating the Telephones 14
Boss & Secretary feature 85
Broadcasting 108, 212
Built-in Simplified Voice Message 91, 211
Busy Station Signalling (BSS) —> Call Waiting 37
Busy Tone 220

C

Call Forwarding (CF)—by ISDN 89, 211
Call Forwarding (FWD) 19, 85
Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls 21, 188
Call Forwarding [FWD] for your Incoming Call Distribution Group 87
Call Forwarding to Voice Mail (Voice Mail Integration) 138
Call Hold 62, 209
Call Hold Retrieve 63, 209
Call Log 21, 189
Call Log for ICD Group 21, 189
Call Monitor 43, 217
Call Park 21, 64, 189, 209
Call Park (Automatic Park Zone) 21, 64, 189, 209
Call Park Retrieve 65
Call Pickup 53
Call Pickup Deny 53, 209
Call Splitting 66
Call Transfer 58
Call Transfer (CT)—by ISDN 60, 209
Call Waiting 37, 68, 115, 212
Call Waiting from the Telephone Company 210
Call Waiting in the PBX 210
Call Waiting Selection 181
Call Waiting Tone 217
Call Waiting Tone Type Selection 181
Calling an Outside Party 26
Calling Another Extension 25
Calling Line Identification Restriction (CLIR) 22, 118, 179, 190, 213
Calling through DISA 47
Calling with the Incoming Call Log 145
Calling with the Outgoing Call Log 147
Calling without Restrictions 46
Calling/Connected Line Identification Presentation (CLIP/COLP) 116, 179, 213
CANCEL 20
CCBS Cancel 37, 208
Changing Call Charges and Extension Control 194
Changing the Settings of Other Extensions 158
Charge Reference 21, 189
Check-in 22, 167, 190
Checking the Time Service Status 122
Check-out 22, 168, 190
Clearing Features 186
Clearing Features Set at Your Extension (Extension Feature Clear) 125
CO 17
Completion of Calls to Busy Subscriber (CCBS) 36, 217
Conference 19, 21, 72, 189
Confirmation Tones 220
Connected Line Identification Restriction (COLR) 22, 117, 190, 213
Connection Example 24
Control Features 158
CTI 22, 190
Customised Buttons 20
Customising the Buttons 188
Customising Your Phone & System 175
Customising Your Phone (Personal Programming) 176
Customising Your System (System Programming) 196

D

Data Line Security 121, 213
Date & Time [000] 199
Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny) 53
Dial Tone Transfer 161
Dial Tones 218
Direct Inward System Access (DISA) 47

With Compliments
Absolute Phone & Data

Direct Station Selection (DSS) 21, 188
Display 15
Display Backlight Selection 179
Display Language Selection 179
Display Lock 183
Display Switching Mode 179
Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]) 116
DND Override 43, 217
Do Not Disturb (DND) 19, 113, 210
Do Not Disturb (DND) Tone 220
Door Open 134, 214
Doorphone Call 133, 214
During a Conversation 58

E

Easy Dialling 30
Electronic Station Lockout —> Extension Dial Lock 103, 183, 212
ENTER 20
Entering Characters 151
Examples 16
Exclusive Call Hold 62
Executive Busy Override 41, 217
Executive Busy Override Deny 119, 182, 213
Extension Control 158
Extension Dial Lock 183, 212
Extension Feature Clear 125, 214
Extension Name [004] 202
Extension Number [003] 201
Extension PIN (Personal Identification Number) 176, 183, 216
External Background Music (BGM) 162, 215
External Feature Access (EFA) 21, 137, 189, 214

F

Feature Highlights 2
Feature Number Table 207
Feature Numbers 14
Fixed Buttons 17
FLASH/RECALL 19
For Future Reference 8
Forced Answerback Selection 181
Forwarding a Waiting Call (Manual Queue Redirection) 132
Forwarding Calls 85
Forwarding Your Calls (Call Forwarding [FWD]) 85
Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN) 89
FWD N/A Timer 182
FWD/DND Cycle Switch Mode 88, 113
FWD/DND Setting Mode 88, 113
FWD/DND—Intercom calls 21, 188
FWD/DND—Outside calls 21, 188

G

Group FWD—Both calls 21, 189
Group FWD—Intercom calls 21, 189
Group FWD—Outside calls 21, 189
Group Paging 105, 212
Group-CO (G-CO) 20, 188

H

Handset/Headset Selection —> Headset Operation 83, 182
Hands-free Answerback 52
Hands-free operation 82
Headset 22, 190
Headset Operation 83, 182
HOLD 18
Holding 62
Holding a Call 62
Holding in a System Parking Zone (Call Park) 64
Hot Line 32, 207
How to Follow the Steps 23
Hurry-up 21, 189
Hurry-up Transfer —> Manual Queue Redirection 132

I

Icon Descriptions 16, 197
Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) 57
If a Doorphone/Door Opener is Connected 133
If a Host PBX is Connected 137
If a Voice Processing System is Connected 138
If an External Relay is Connected 135
If an External Sensor is Connected 136
Incoming Call Distribution Group (ICD Group) 21, 188
Incoming Call Distribution Group Monitor 129, 214
Incoming Call Log 145
Indication Tones 220
INTERCOM 18
Intercom Call 25
ISDN Service 22, 190
ISDN Service Access 44
ISDN-Hold 22, 190

J

Jog Dial 20
Joining an Existing Call (Executive Busy Override) 41

K

Key Pad Tone Set 182
KX-TDA100/KX-TDA200 MPR Version 1.1 222
KX-TDA100/KX-TDA200 MPR Version 2.0 223
KX-TDA30 MPR Version 1.1 224
KX-TDA30 MPR Version 2.0 225
KX-TDA30 MPR Version 2.2 226

L

Last Number Redial 34, 207
LCS Mode Set (After Answering) 181
Leaving a Conference (Leaving Three-party Conference) 76
Leaving a Conference (Unattended Conference) 75
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting) 38
Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) 126
Leaving Three-party Conference 76
Leaving Voice Messages 95
Letting a Third Party Join Your Call (Privacy Release) 78

With Compliments
Absolute Phone & Data

Letting Other People Listen to the Conversation (Off-hook Monitor) 82
Listening to Voice Messages Left by Callers 96
Live Call Screening 22, 140, 190
Live Call Screening Mode Set 181
Log-in/Log-out 21, 126, 189, 214
Log-in/Log-out for all groups 21, 189
Log-in/Log-out of a specified group 21, 189
Loop-CO (L-CO) 20, 188

M

Making a Call to a Private Network (TIE Line Access) 28
Making an Announcement and Having a Multiple Party Conversation (Broadcasting) 108
Making Calls 25
Making/Answering an Announcement 105
Malicious Call Identification (MCID) 57, 209
Manager Operation 157
Manager Password 193
Manager Programming 193, 194
Manual Queue Redirection 132
Message 17, 21, 188
Message for Another Extension 21, 188
Message Waiting 38, 208, 217
MODE 20
MONITOR 18
Monitoring and Changing the Log-in/Log-out Status of Extensions 130
Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) 129
Monitoring Another Extension (Call Monitor) 43
Monitoring the Status of Waiting Calls 129
Multiple Party Conversation 72
Mute 81

N

Navigator Key 20
Network Direct Station Selection (NDSS) 22, 190

O

Off-hook Call Announcement (OHCA) 115
Off-hook Monitor 82
One-touch Dialling 21, 30, 188
One-touch Dialling Assignment Mode Selection 183
One-touch Transfer 59
One-touch Two-way Transfer 22, 142, 190
Opening a Door (Door Open) 134
Operation 13
Operator Call 26, 207
Outgoing Call Log 147
Outgoing Messages (OGM) 163, 215
Outside Line Group Access 27, 207

P

Paging 105
Paging and then Transferring a Call 105
Paging Deny 107, 182
Parallelled Telephone 123, 180, 213
PAUSE 17
Personal Absent Message 181
Personal Programming 176
Personal Speed Dialling 30, 207
Pickup Dialling —> Hot Line 32, 207
Predialling 27
Preferred Line Assignment—Incoming 180
Preferred Line Assignment—Outgoing 180
Preventing Other People from Joining Your Conversation (Executive Busy Override Deny) 119
Preventing Other People from Using Your Telephone (Extension Dial Lock) 103
Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) 118
Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) 117
Privacy Release 78
PROGRAM 19
Programmable Feature (PF) 20
Programming Information 193, 196
Protecting Your Line against Notification Tones (Data Line Security) 121

Q

Quick Dialling 33

R

Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) 115
Receiving Calls 51
Recording a Conversation 142
Recording a Greeting Message for Each Time Mode 93
Recording a Normal Greeting Message 91
Recording Outgoing Messages (OGM) 163
Recording room information using a room extension 172
Redial 17, 34
Redialling the Last Number You Dialled (Last Number Redial) 34
Redirecting Your Calls to Your Message Box 94
Refusing Incoming Calls (Do Not Disturb [DND]) 113
Registration for Your Portable Station (PS) 14
Release 20, 22, 55, 190
Releasing Network Direct Station Selection (NDSS) Monitor 173
Remote COS Access 46, 208
Remote Extension Dial Lock 158, 215
Remote Setting 50, 208
Remote Station Lock Control —> Remote Extension Dial Lock 158, 215
Reorder Tone 220
Required Telephone 193, 196
Reserving a Busy Line (Automatic Callback Busy) 35
Restriction Level Control (Dial Tone Transfer) 161
Restrictions 16
Revision History 222
Ring Tones 218

S

Safety Instructions 5
Screening Calls (Live Call Screening [LCS]) 140
SELECT 20
Sending a Call Waiting Notification (Call Waiting) 37
Setting a Timed Reminder to a Room Extension (Remote Wake-up Call) 171
Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber

With Compliments Absolute Phone & Data

[CCBS]) 36
Setting Features 178
Setting the Alarm (Timed Reminder) 111
Setting the Parallelled Telephone to Ring (Parallelled Telephone) 123
Setting the Telephone According to Your Needs 111
Setting Your Telephone from Another Extension or through DISA (Remote Setting) 50
Settings on the Programming Mode 178
SHIFT 20
Showing a Message on the Caller's Telephone Display (Absent Message) 101
Single-CO (S-CO) 21, 188
Soft Buttons 18
SP-PHONE 17
Station Programme Clear —> Extension Feature Clear 125, 214
Station Speed Dialling —> Personal Speed Dialling 30, 207
Storing Names and Numbers 150
System Alarm 21, 189
System Feature Access 156
System Password 196
System Programming 196, 199
System Speed Dialling 31, 207
System Speed Dialling Name [002] 201
System Speed Dialling Number [001] 200

T

Talking to Two Parties Alternately (Call Splitting) 66
Terminate 21, 189
Three-party Conference [3PTY]—by ISDN 79, 210
TIE Line Access 28, 207
Time Service (Day/Night/Lunch/Break) 21, 122, 159, 189, 215
Time Service Mode Control 159
Time Service Switching Mode (Automatic/Manual) 22, 159, 190
Timed Reminder 111, 212
To Access Another Party Directly from Outside (Direct Inward System Access [DISA]) 47
Toll Restriction/Call Barring 22, 190
Tone 15
TRANSFER 18
Transferring a Call (Call Transfer) 58
Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN) 60
Transferring to an Extension on the PBX 58
Transferring to an Outside Party Using the PBX Service 59
Troubleshooting 204
Trunk Answer From Any Station (TAFAS) 54, 209
Turning on the Background Music (BGM) 120
Turning on the External Background Music (BGM) 162
Two-way Record 22, 142, 190
Two-way Transfer 22, 142, 190

U

Unattended Conference 75
Using a Display Proprietary Telephone 145
Using a Navigator Key/Jog Dial/Volume Key 15
Using a Preprogrammed Number (Quick Dialling) 33
Using an Account Code (Account Code Entry) 29
Using Numbers Stored at Your Extension (Personal Speed Dialling) 30
Using Numbers Stored in the PBX (System Speed Dialling) 31
Using the ANSWER/RELEASE Button 55
Using the Directories 149
Using the Headset (Headset Operation) 83
Using the Same Settings as Your Previous Extension (Walking Extension) 144
Using the Telephones in a Hotel-type Environment (Hospitality Features) 167
Using User-supplied Equipment 133
Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (KX-TDA30 only) 91
Using Your Calling Privileges at Another Extension (Remote COS Access) 46
Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) 124
Utilising the Call Centre 126

V

Verified Code Entry 46, 208
VOICE CALL/MUTE 19
Voice Mail Integration 138, 214
Voice Mail Transfer 22, 138, 190
Volume Key 20

W

Walking COS 46
Walking Extension 144, 215
Walking Station —> Walking Extension 144, 215
Warning Tone 220
What is This Tone? 218
What Kind of Telephone Can Be Used? 14
When the Dialled Line is Busy or There is No Answer 35
When You Use a Panasonic Proprietary Telephone 17
Whisper OHCA 115
Wireless XDP Parallel Mode 124, 214
With a One-touch Button (One-touch Dialling) 30
Wrap-up 21, 126, 189

Y

Your Extension Number 15

With Compliments
Absolute Phone & Data

With Compliments
Absolute Phone & Data

Panasonic Communications Co., Ltd.
1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:
This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2003 Panasonic Communications Co., Ltd. All Rights Reserved.

PSQX2635TA KK0103EK6065